

# Operating Instructions

## VA7015QT

**ATAG**



# Contents

|                                   |    |                                |    |
|-----------------------------------|----|--------------------------------|----|
| Front panel                       | 2  | Troubleshooting                | 16 |
| Safety instructions               | 3  | Technical information          | 19 |
| Before washing for the first time | 4  | Installation                   | 20 |
| Loading the dishwasher            | 6  | Service                        | 21 |
| Using the dishwasher              | 8  | Information for test institute | 22 |
| Settings                          | 12 | Your notes                     | 23 |
| Care and cleaning                 | 14 | Quick guide                    | 24 |

Dear ATAG customer!


We hope that you will have many years of use from your new machine.

To get the most out of your new dishwasher, we recommend that you read the operating instructions before using the dishwasher. The last page also includes a Quick guide.

## Front panel

To switch on the dishwasher, press and hold the main power switch until the display lights up.

**"This is a first time set up."** is shown on the display the first time the dishwasher is switched on. It is important that you choose the right settings to ensure good dishwashing results. See page 4.



# Safety instructions

- Read the operating instructions and keep them in a safe place!
- Number of standard place settings: 13
- Never use the dishwasher for any purpose other than that specified in these operating instructions.
- Do not load the dishwasher door or dishwasher baskets with anything other than dishes.
- Never leave the dishwasher door open as someone may trip on it.
- Use only dishwasher detergent!
- This machine can be used by children aged 8 and upwards, and by people with reduced physical capacity, mental ability, memory loss or lacking experience and knowledge. These individuals must be supervised when using the machine or have instructions on how to use the machine and understand the risks that can occur. Cleaning of the machine must not be carried out by children without supervision.
- Children must be watched to ensure they do not play with the dishwasher.
- Damaged mains cables must only be replaced by a qualified electrician.
- Only use the dishwasher in household-type environments for dishwashing household dishes. All other use is prohibited.
- Never place dishes with solvent residues in the dishwasher due to the risk of explosion. Nor may dishes that contain ash, wax or lubricants be washed in the dishwasher.

## WARNING!

Knives and other pointed items must be placed with the points down in the cutlery basket or horizontally in other baskets.

## WARNING!

Children must be supervised – dishwasher detergent is corrosive!

### **Activate child lock (button lock)**

You can activate the child lock (button lock) to prevent children from starting the dishwasher. See the chapter Settings.

## Winter storage/Transport

- Store the dishwasher where the temperature remains above freezing.
- Avoid long transport distances in very cold weather.
- Transport the dishwasher upright or laying on its back.

## Overflow guard function

The overflow protection starts pumping out the machine and turns off the water supply if the water level in the dishwasher exceeds the normal level. If the overflow protection is triggered, turn off the water supply and call the service department.

## Packing material

The packaging protects the product during transport. The packaging material is recyclable. Separate the different packaging materials to help reduce raw material use and waste. Your dealer can take the packaging for recycling or direct you to the nearest recycling centre. The packaging is comprised of:

- Corrugated cardboard made from up to 100% recycled material.
- Expanded polystyrene (EPS) with no added chlorine or fluorine.
- Supports made from untreated wood.
- Protective plastic made from polyethylene (PE).

## Disposal

- When the dishwasher has reached the end of its service life and is to be disposed of, it should immediately be made unusable. Pull out the power cable and cut it as short as possible.
- The dishwasher is manufactured and labelled for recycling.
- Contact your local authority for information about where and how your dishwasher should be correctly recycled.

## Installation

See the section Installation.

## Child safety

- Always start the dishwasher immediately after adding detergent.
- Keep children away from the dishwasher when the door is open. Some detergent may remain inside!
- Do not allow children to use or play with the dishwasher. Be especially vigilant when the door is open.

# Before washing for the first time

## 1. Checking water hardness

In order to achieve good dishwashing results, the dishwasher needs soft water (water with low mineral content). Hard water leaves a white coating on dishes and the dishwasher.

Water hardness is specified using the following scales: The German water hardness scale (°dH) and the French water hardness scale (°fH). A water supply with a water hardness in excess of 6°dH (9°fH) must be softened. This is done automatically with the aid of the built-in water softener. In order for the softener to function optimally, it must be adjusted to the hardness of the water supply.

Contact the local waterworks, or measure the water hardness using the supplied test strip, to check the water hardness in your area. Once you have adjusted the water softener, use detergent and rinse aid doses suitable for soft water.

### How to use the test strip:


- 1 Turn on the water tap and let the water run for a minute or so.
- 2 Fill a glass with water.
- 3 Remove the test strip from its packaging.
- 4 Dip the test strip in the water for about one second.
- 5 Wait one minute. Now compare the colours of the squares with the water hardness table.

| Test strip   | °dH | °fH |
|--------------|-----|-----|
| 4 green □□□□ | <3  | <5  |
| 1 red ■□□□   | >4  | >7  |
| 2 red ■■□□   | >8  | >15 |
| 3 red ■■■□   | >14 | >25 |
| 4 red ■■■■   | >21 | >38 |

## 2. Basic settings

To switch on the dishwasher, press and hold the main power switch until the display lights up.

**"This is a first time set up."** is shown on the display. It is important that you choose the right settings to ensure good dishwashing results.



### Settings

#### 1 Language

Select the language to be shown on the display.

#### 2 Rinse aid 0/1/2/3/4/5/TAB

Drying is faster and a better result is achieved if you use rinse aid. You will also achieve a better dishwashing result with clear and spotless dishes.

Select rinse aid dosage. The rinse aid dispenser can be adjusted between 0 (Off) and 5 (High dosage).

When using an all-in-one detergent that contains rinse aid, you can activate the setting TAB. Read more about all-in-one detergent in the chapter Using the dishwasher.

*Pre-selected at factory: 5*

#### 3 Water hardness 0/1/2/3/4/5/6/7/8/9

Choose a setting depending on the hardness of the water supply. See the water hardness table below. It is important that this setting is correct!

| °dH   | °fH   |   | °dH   | °fH   |   |
|-------|-------|---|-------|-------|---|
| 0-5   | 0-9   | 0 | 20-24 | 35-43 | 5 |
| 6-8   | 10-14 | 1 | 25-29 | 44-52 | 6 |
| 9-11  | 15-20 | 2 | 30-39 | 53-70 | 7 |
| 12-14 | 21-25 | 3 | 40-49 | 71-88 | 8 |
| 15-19 | 26-34 | 4 | 50+   | 89+   | 9 |

Do not forget to put salt in the salt compartment after you have set the water softener to 1 - 9.


*For a water supply with a hardness under 6°dH (9°fH), select 0. The water softener is deactivated and no salt is needed.*

*Pre-selected at factory: 4*

*To change the chosen setting, see the chapter Settings.*

### 3. Top up with rinse aid

Drying is faster and a better result is achieved if you use rinse aid. You will also achieve a better dishwashing result with clear and spotless dishes.



- 1 Open the rinse aid compartment lid.
- 2 Carefully top up with rinse aid. Only add rinse aid to the level marked **max**.
- 3 Wipe up any splashes of rinse aid around the compartment.
- 4 Close the lid firmly.



#### Top up rinse aid

When the rinse aid needs topping up, the above symbol lights on the display.

After topping up, it may take a while before the symbol goes out.

#### NOTE!

##### Increase the rinse aid dosage:

- If the dishes have water marks.

##### Decrease the rinse aid dosage:

- If the dishes have a sticky white/blue film.
- If the dishes are streaked.
- Build-up of foam. If you have very soft water, the rinse aid can be diluted 50:50 with water.

### 4. Top up with salt

Before you begin using a dishwasher with a water softener, you must fill the salt compartment with salt for the water supply to be softened automatically. Use large grain salt or special dishwasher salt.




#### WARNING!

In order to avoid rust stains a dishwashing programme must be started immediately after adding salt.

Never pour dishwasher detergent into the salt compartment. This destroys the water softener!

#### Do as follows the first time:

- 1 Unscrew the lid as illustrated.
- 2 Place the funnel supplied with the dishwasher in the salt compartment top-up hole. First, pour in about 1 l of water.
- 3 Then add salt, a maximum of 1.0 kg, until the compartment is full.
- 4 Wipe up any excess salt so that the lid can be screwed on firmly.
- 5 Run a programme to ensure that any salt in the dishwasher is rinsed away.



#### Top up salt

When the salt needs topping up, the above symbol lights on the display.

When the salt runs out, unscrew the cap and fill the container with salt. Water is only needed the first time! Wipe clean and tighten. Run a programme to ensure that any salt in the dishwasher is rinsed away.

After topping up, it may take a while before the symbol goes out.

# Loading the dishwasher

## Energy-efficient dishwashing

### Run programmes only with a full load

Wait to run a programme until the dishwasher is full, this way you save energy. Use the Rinse and hold programme to rinse the dishes if there are any unpleasant odours while you wait for the dishwasher to become fully loaded.

### Run programmes at a lower temperature

If the dishes are only slightly dirty, you can select a programme with a low temperature.

### Select Green mode

The dishwasher has different programme modes. To save energy and water, use Green mode.

Better drying results are achieved if you open the door a little once the programme has ended. (If the dishwasher is built-in the surrounding furnishings must be resistant to any condensation from the dishwasher.)

### Do not rinse under running water

Simply scrape off large food particles before loading the dishwasher.

### Choose a green detergent

Read the environmental declaration on the packaging!

### Connect to cold water

Connect the dishwasher to the cold water supply if the building is heated using oil, electricity or gas.

### Connection to hot water supply

Connect the dishwasher to the hot water supply (max. 70 °C) if the building is heated using an energy-efficient means such as district heating, solar power or geothermal power. Choosing a hot water connection cuts dishwashing times and reduces the dishwasher's energy consumption.

#### NOTE!

Do not exceed the permitted water supply temperature. Certain materials used in some cookware cannot withstand strong heat.

## Fragile dishes

Some cookware is not dishwasher safe. This can be for several reasons. Some materials cannot withstand strong heat, others can be damaged by dishwashing detergent.

Exercise caution with, for example, handmade items, fragile decoration, crystal/glassware, silver, copper, tin, aluminium, wood and plastic. Look for the "Dishwasher safe" marking.

### Fragile decoration

Porcelain with decoration on top of the glazing (the items feel rough) should not be washed in a dishwasher.

### Crystal/Glass

Wash fragile items made of crystal/glass using the gentle dishwashing programme Crystal glass. Remember to use a small amount of detergent and to place items so that they do not touch each other during the wash.

Drying is faster and a better result is achieved if you use rinse aid. You will also achieve a better dishwashing result with clear and spotless dishes.

*Hand-painted glassware, as well as antique and very fragile items, should not be washed in a dishwasher.*

### Silver

Silver and stainless steel items should not come into contact, as the silver can become discoloured.

### Aluminium

Aluminium can lose its shine if washed in a dishwasher. However, good quality aluminium pans can be washed in a dishwasher, even if some of the shine will be lost.

### Cutlery with glued handles

Some types of glue are not dishwasher safe. In such cases, the handles may loosen.

## Points to consider

- All dirty surfaces should face inwards and downwards!
- Dishes should not be placed in or on each other.
- Angle dishes with hollows, such as cups, so that the rinse water will run off. This is also important for plastic items.
- Make sure small items cannot fall through the dishwasher basket; place them in the cutlery basket.

#### NOTE!

Check that the spray arms can rotate freely.



## The dishwasher's baskets

The dishwasher is equipped with an upper basket and a lower basket with a cutlery basket.

*The appearance of the baskets may differ depending on the dishwasher setup.*

### Upper basket

Place glasses, cups, bowls, side plates and saucers in the upper basket. All dirty surfaces should face inwards and downwards! Wine glasses are placed on the wine glass shelf and knives are placed in the knife stand on the right (if fitted).




#### Raising the upper basket

- 1 Pull out the upper basket.
- 2 Grab the sides of the upper basket with both hands and lift it up.

#### Lowering the upper basket


- 1 Pull out the upper basket.
- 2 Pull out the two locking handles on either side to lower the upper basket.



### Lower basket


Place plates, side plates, serving dishes, pots and cutlery (in the cutlery basket) in the lower basket.

Place pots and pans in the rear right of the lower basket to best utilise dishwashing performance from the rear spray nozzle, which is intended for these types of dishes.



#### Foldable tines

Lower the foldable tines (plate supports) when washing pots. Release the foldable tines by pressing the catch inwards before adjusting their position.



#### Washing large plates

Move foldable tines and their mounts to widen the distance between the tine rows to adapt the lower basket to plates with a diameter greater than 25 cm.

### Cutlery basket

Place cutlery with the handles facing down, except for knives, and spread them out as much as possible. Ensure that spoons do not stack inside each other.


The cutlery basket is best placed in the middle at the front of the lower basket to best utilise dishwashing performance from the unique spray nozzle, which is intended for the cutlery basket.

#### ! WARNING!

Knives and other pointed items must be placed with the points down in the cutlery basket or horizontally in other baskets.


#### Fold-down section for small items

The cutlery basket has a fold-down section in the middle for small items, or small shafts, such as electric whisk attachments.




# Using the dishwasher


## Cutlery basket with lid



The cutlery basket lid can be removed and used, for example, as an extra cutlery basket in the upper basket (see below).



## Add detergent



- 1 Prewash detergent compartment
- 2 Main wash detergent compartment

Detergent is added according to water hardness.

Follow the instructions on the detergent packaging. This dishwasher is fitted with a water softener, so use detergent and rinse aid doses suitable for soft water.

Too much detergent can result in less effective dishwashing and also entails greater environmental impact.

The detergent compartment must be dry when adding detergent. There is one compartment for the prewash and one for the main wash. If powder or liquid dishwasher detergent is used, add a small amount of the detergent to the prewash compartment. Contact the detergent manufacturer if you have questions about the detergent.

### NOTE!

Use only dishwasher detergent! Washing up liquid must not be used as the foam that forms prevents the dishwasher from operating effectively.

## Dishwasher tablets

Halve the tablet if it is difficult to close the dispenser lid. There is a risk that the detergent will not be released properly if the lid is tight and will not open correctly.

### NOTE!

Dishwasher tablets are not recommended for short programmes (less than 75 minutes). Use powder or liquid dishwasher detergent instead.


## All-in-one detergent

There are many types of all-in-one detergents on the market. Read through the directions for these products carefully.

When using an all-in-one detergent that contains rinse aid, you can activate the setting TAB. Note that the salt compartment must be filled with salt.

### NOTE!

Optimal washing and drying results are achieved by using normal detergent together with separately dispensed rinse aid and salt.



## The main power switch

Press and hold the main power switch until the display turns on. Also check that the water tap is on.

## Select a programme

To select a programme, press the Navigation button < or > until the desired programme is shown on the display.

Select a programme to suit the type of dishes and how dirty they are.

### **ECO wash**

This programme is intended for cleaning normally dirty dishes and is the most effective programme in terms of combined energy and water consumption.

### **Normal wash**

Powerful programme for daily use that can remove dried leftovers, but is not intended for burnt food, such as on oven dishes. This programme provides maximum rinse effect, and takes longer than Daily wash.

### **Daily wash**

An effective programme for daily use for slightly dried leftovers. (This programme is not intended for burnt food, such as on oven dishes.)

### **Time program**

The programme adapts to the specified running time or finish time. With this programme it is important to choose a time suited to how dirty the dishes are.

|           |                       |
|-----------|-----------------------|
| 0:15-0:45 | Slightly dirty dishes |
| 1:00-1:30 | Normally dirty dishes |
| 2:00-2:30 | Very dirty dishes     |

 – To set the desired programme time, press and hold the option button to set the desired programme length.

### **Rinse and hold**

Used to rinse dishes while you wait for the dishwasher to become fully loaded.

### **Plastic wash**

A programme intended for washing plastic items that are dishwasher safe. This programme has an extra long drying cycle. Porcelain and glasses can also be washed.

### **Hygiene wash**

This programme is ideal to use where demands on hygiene are extra high, e.g. for baby bottles and cutting boards. The temperature is high both in the main wash and in the final rinse.

### **Crystal glass**

A gentle dishwashing programme with a low temperature for washing fragile items made of crystal/glass. Remember to use a small amount of detergent and to place items so that they do not touch each other during the wash. See also Fragile dishes in the chapter Loading the

dishwasher. Porcelain that has just been used without dried leftovers can also be washed using this programme.

### **Quick Pro wash**

Shorten the dishwashing programme by preheating the water. This programme is not intended for dried leftovers. Remember to scrape off larger food particles before loading the dishwasher.

- 1 To prepare the programme, press and hold Start/Stop until the display shows "Preheating". Close the door. Wait until the display shows "Preheating ready".  
You can load the dishes while the water is being preheated.
- 2 To start the programme, press and hold Start/Stop until the display shows "Program started, close door". This indicates that the dishwasher is ready to start. Close the door properly, otherwise the dishwasher will not start.

### **Self-cleaning**

Self-cleaning programme for hygienic cleaning of the dishwasher tub, spray arms and spray pipes.

This programme can be run (with no dishes in the machine) using normal dishwasher detergent or citric acid. Special dishwasher cleaners are also available on the market. For the removal of limescale deposits, see The dishwasher tub in the chapter Care and cleaning.

### **Upper half wash**

You can use this programme if you only have cups and glasses that need washing in the upper basket. Slightly dirty dishes can also be placed in the lower basket.

### **Lower half wash**

You can use this programme when you only want to wash plates and cutlery in the lower basket. Slightly dirty dishes can also be placed in the upper basket.

## Select a programme mode

To select a programme mode, press the programme mode selector until the desired mode is shown on the display. The available programme modes vary between programmes.

For a brief description, press and hold the programme mode selector.

### **Green mode**

The dishwasher uses less energy and water. The programme time is extended.

### **Speed mode**

The programme time is shortened, but the dishwasher uses more energy and water.

### **Night mode**

Lower noise level during the dishwashing programme. The programme time is extended.

### **Intensive mode**

Improves the dishwashing results, but the dishwasher uses more energy and water. The programme time is extended.

## Select an option

To select an option, press the option button until the desired option is shown on the display. The available options vary between programmes.

### ☄ Extra Dry

A higher temperature in the final rinse and a longer drying cycle improve the drying results if you activate this option. Energy consumption is slightly increased.

For a brief description, press and hold the button for Extra Dry.

### 🕒 Delayed Start

When you select Delayed Start, the dishwasher will start 1-24 hours after you have pressed the button Start/Stop and closed the door.

- 1 Press the button once to activate Delayed Start. Press the button several times – or hold it in – to set the desired number of hours.
- 2 Press Start/Stop and close the door. The timer counts down and the dishwasher starts after the selected delay.

If you want to cancel the Delayed Start option, open the door and press and hold the main power switch until the display turns off.

### **START STOP** Starting the dishwasher

Press and hold Start/Stop until the display shows "Program started, close door". This indicates that the dishwasher is ready to start. Close the door properly, or the dishwasher will not start.

If the dishwasher is not started or the door is not closed within 2 minutes of the last button press, the machine switches off.

## Time remaining

Once you have chosen a programme, programme mode and options, the time the programme took when last used is displayed.

## Stopping or changing a programme

If you want to change programme after starting the dishwasher, open the door then press and hold Start/Stop for three seconds. Add more detergent if the lid of the detergent dispenser has opened. Then choose a new programme, press Start/Stop and close the door.

## If you want to load more dishes

Open the door. The dishwasher stops automatically. Add the dishes and close the door. After a while, the dishwasher continues the programme.

## If the dishwasher is turned off due to a power failure

If the dishwashing programme was not finished, the interrupted programme continues when power is restored.

### NOTE!

During drying, the programme is interrupted if the power is cut or the door is open for more than 2 minutes.

## Once the programme has finished

Once the programme has finished and the door is opened "Ready" appears on the display.

At the end of the programme one short signal will sound. Chapter Settings describes how to change this function.

The dishwasher switches off automatically after the programme ends. Shut off the water tap after each use.

## How to get the best drying results

- Fully load the dishwasher.
- Angle dishes with hollows, such as cups, so that the rinse water will run off. This is also important for plastic items.

- Top up with rinse aid or increase the rinse aid dosage level.
- Activate the Extra Dry option.
- Activate the High temperature setting. See the chapter Settings.
- Open the door a little once the programme has finished.
- Allow the dishes to cool before unloading the dishwasher.

## Unloading the dishwasher

Hot porcelain is more fragile. Leave the dishes to cool in the dishwasher before unloading them.

Unload the lower basket first to avoid any water drops from the upper basket falling onto the dishes in the lower basket.

## Programme chart

| Programme              | Detergent, compartment 2 (ml) | Prewashes | Main wash | Number of rinses | Final rinse | Consumption values <sup>1)</sup>   |                      |                                    |                      |                     |
|------------------------|-------------------------------|-----------|-----------|------------------|-------------|------------------------------------|----------------------|------------------------------------|----------------------|---------------------|
|                        |                               |           |           |                  |             | Cold water <sup>2)</sup>           |                      | Hot water <sup>3)</sup>            |                      | Water cons. (liter) |
|                        |                               |           |           |                  |             | Dishwashing time (approx. hrs:min) | Energy (approx. kWh) | Dishwashing time (approx. hrs:min) | Energy (approx. kWh) |                     |
| ECO wash <sup>4)</sup> | 25                            | 1         | 52 °C     | 3                | 47 °C       | 5:10                               | 0.82                 | 4:50                               | 0.5                  | 12.7                |
| Normal wash            | 25                            | 2         | 60 °C     | 2                | 65 °C       | 2:25                               | 1.2                  | 2:05                               | 0.6                  | 13                  |
| Daily wash             | 25                            | 2         | 60 °C     | 2                | 65 °C       | 1:55                               | 1.2                  | 1:35                               | 0.6                  | 15                  |
| Time program           | 25                            | 0-2       | <65 °C    | 2-3              | <65 °C      | 0:15-2:30                          | 0.5-1.6              | 0:15-2:30                          | 0.4-1.2              | 11-19               |
| Rinse and hold         |                               |           |           | 1                | --- °C      | 0:07                               | 0.01                 | 0:07                               | 0.01                 | 3                   |
| Plastic wash           | 25                            | 1         | 50 °C     | 2                | 68 °C       | 2:45                               | 1.1                  | 2:25                               | 0.6                  | 12                  |
| Hygiene wash           | 25                            |           | 70 °C     | 2                | 70 °C       | 1:10                               | 1.4                  | 1:00                               | 0.9                  | 10                  |
| Crystal glass          | 20                            |           | 45 °C     | 2                | 50 °C       | 1:40                               | 0.8                  | 1:20                               | 0.5                  | 9                   |
| Quick Pro wash         | 20                            |           | 60 °C     | 2                | 55 °C       | 0:30 + 0:20                        | 0.9                  | 0:20 + 0:20                        | 0.6                  | 10                  |
| Upper half wash        | 20                            | 1         | 60 °C     | 2                | 60 °C       | 2:10                               | 1.0                  | 1:50                               | 0.6                  | 12                  |
| Lower half wash        | 20                            | 1         | 60 °C     | 2                | 60 °C       | 2:10                               | 1.0                  | 1:50                               | 0.6                  | 12                  |

<sup>1)</sup> Consumption values vary depending on the temperature of the incoming water, room temperature, load size, selected additional functions and more.

<sup>2)</sup> Connection to cold water, approx. 15 °C.

<sup>3)</sup> Connection to hot water, approx. 60 °C.


<sup>4)</sup> This dishwashing programme is the standard cleaning cycle used to compile the energy labelling information. It is intended for washing normally dirty dishes and is the most effective programme in terms of combined energy and water consumption.

# Settings

## Open the dishwasher's Settings menu

To open the dishwasher's Settings menu, press the Navigation button < or > until Settings menu is shown on the display and confirm your selection with the mode selector .

To exit the dishwasher's Settings menu, select Exit and confirm your selection with the mode selector .




| Settings                   | Options                                                                                                                                                                                                                                                                                                                                                                   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|----------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1. <b>Language</b>         | English/Svenska/Dansk/Norsk/Suomi/<br>Nederlands/Français/Deutsch/Italiano/<br>Русский/Español/Português/Sloven./<br>Eesti/Latviešu/Lietuvių/Hrvatski/Polish                                                                                                                                                                                                              | You can choose the language used for the display.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| 2. <b>Select programs</b>  | Normal wash <i>On/Off</i><br>ECO wash <i>On/Off</i><br>Daily wash <i>On/Off</i><br>Time program <i>On/Off</i><br>Rinse and hold <i>On/Off</i><br>Plastic wash <i>On/Off</i><br>Hygiene wash <i>On/Off</i><br>Crystal glass <i>On/Off</i><br>Quick Pro wash <i>On/Off</i><br>Self-cleaning <i>On/Off</i><br>Lower half wash <i>On/Off</i><br>Upper half wash <i>On/Off</i> | Programmes can be shown or hidden in the menu. Choose between On and Off.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| 3. <b>Child lock</b>       | <i>On/Off</i>                                                                                                                                                                                                                                                                                                                                                             | You can activate the child lock (button lock) to prevent children from starting the dishwasher.<br><br><  To temporarily deactivate and activate the child lock, press and hold the left Navigation button and the option button Delayed Start for 3 seconds.                                                                                                                                                                                                                                                               |
| 4. <b>Display settings</b> | Contrast top display 1/2/3/4                                                                                                                                                                                                                                                                                                                                              | For adjusting the contrast of the display.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 5. <b>Feedback sound</b>   | 0/1/2/3                                                                                                                                                                                                                                                                                                                                                                   | This sound is used to confirm each button press.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| 6. <b>Buzzer volume</b>    | 0/1/2/3                                                                                                                                                                                                                                                                                                                                                                   | The buzzer indicates when a dishwashing programme has ended.<br><i>Error messages are always indicated by a loud buzzer.</i>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| 7. <b>Rinse aid</b>        | 0/1/2/3/4/5/TAB                                                                                                                                                                                                                                                                                                                                                           | Setting for rinse aid dosage. The rinse aid dispenser can be adjusted between 0 (Off) and 5 (High dosage).<br>Increase the rinse aid dosage: <ul style="list-style-type: none"> <li>• If the dishes have water marks.</li> </ul> Decrease the rinse aid dosage: <ul style="list-style-type: none"> <li>• If the dishes have a sticky white/blue film.</li> <li>• If the dishes are streaked.</li> <li>• Build-up of foam. If you have very soft water, the rinse aid can be diluted 50:50 with water.</li> </ul> When using an all-in-one detergent that contains rinse aid, you can activate the setting TAB. |

| Settings |                  | Options             |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |       |     |  |     |     |  |     |     |   |       |       |   |     |       |   |       |       |   |      |       |   |       |       |   |       |       |   |       |       |   |       |       |   |     |     |   |
|----------|------------------|---------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------|-----|--|-----|-----|--|-----|-----|---|-------|-------|---|-----|-------|---|-------|-------|---|------|-------|---|-------|-------|---|-------|-------|---|-------|-------|---|-------|-------|---|-----|-----|---|
| 8.       | Super rinse      | On/Off              | <p>Super rinse adds two extra rinses.</p> <p><i>Activated in the following programmes:</i></p> <p><i>Normal wash</i></p> <p><i>ECO wash</i></p> <p><i>Daily wash</i></p> <p><i>Plastic wash</i></p> <p><i>Lower half wash</i></p> <p><i>Upper half wash</i></p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |       |     |  |     |     |  |     |     |   |       |       |   |     |       |   |       |       |   |      |       |   |       |       |   |       |       |   |       |       |   |       |       |   |     |     |   |
| 9.       | High temperature | On/Off              | <p>Activate the setting High temperature to improve the dishwashing results. Energy consumption is slightly increased.</p> <p><i>Activated in the following programmes:</i></p> <p><i>Normal wash</i></p> <p><i>ECO wash</i></p> <p><i>Daily wash</i></p> <p><i>Plastic wash</i></p> <p><i>Quick Pro wash</i></p> <p><i>Lower half wash</i></p> <p><i>Upper half wash</i></p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |       |     |  |     |     |  |     |     |   |       |       |   |     |       |   |       |       |   |      |       |   |       |       |   |       |       |   |       |       |   |       |       |   |     |     |   |
| 10.      | Water hardness   | 0/1/2/3/4/5/6/7/8/9 | <p>Adjusting the water softener. Read off the appropriate setting from the water hardness table below.</p> <table><tr><th>°dH</th><th>°fH</th><th></th><th>°dH</th><th>°fH</th><th></th></tr><tr><td>0-5</td><td>0-9</td><td>0</td><td>20-24</td><td>35-43</td><td>5</td></tr><tr><td>6-8</td><td>10-14</td><td>1</td><td>25-29</td><td>44-52</td><td>6</td></tr><tr><td>9-11</td><td>15-20</td><td>2</td><td>30-39</td><td>53-70</td><td>7</td></tr><tr><td>12-14</td><td>21-25</td><td>3</td><td>40-49</td><td>71-88</td><td>8</td></tr><tr><td>15-19</td><td>26-34</td><td>4</td><td>50+</td><td>89+</td><td>9</td></tr></table> <p>Do not forget to put salt in the salt compartment after you have set the water softener to 1 - 9.</p> <p><i>For a water supply with a hardness under 6°dH (9°fH), select 0.</i></p> <p><i>The water softener is deactivated and no salt is needed.</i></p> | °dH   | °fH |  | °dH | °fH |  | 0-5 | 0-9 | 0 | 20-24 | 35-43 | 5 | 6-8 | 10-14 | 1 | 25-29 | 44-52 | 6 | 9-11 | 15-20 | 2 | 30-39 | 53-70 | 7 | 12-14 | 21-25 | 3 | 40-49 | 71-88 | 8 | 15-19 | 26-34 | 4 | 50+ | 89+ | 9 |
| °dH      | °fH              |                     | °dH                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               | °fH   |     |  |     |     |  |     |     |   |       |       |   |     |       |   |       |       |   |      |       |   |       |       |   |       |       |   |       |       |   |       |       |   |     |     |   |
| 0-5      | 0-9              | 0                   | 20-24                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | 35-43 | 5   |  |     |     |  |     |     |   |       |       |   |     |       |   |       |       |   |      |       |   |       |       |   |       |       |   |       |       |   |       |       |   |     |     |   |
| 6-8      | 10-14            | 1                   | 25-29                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | 44-52 | 6   |  |     |     |  |     |     |   |       |       |   |     |       |   |       |       |   |      |       |   |       |       |   |       |       |   |       |       |   |       |       |   |     |     |   |
| 9-11     | 15-20            | 2                   | 30-39                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | 53-70 | 7   |  |     |     |  |     |     |   |       |       |   |     |       |   |       |       |   |      |       |   |       |       |   |       |       |   |       |       |   |       |       |   |     |     |   |
| 12-14    | 21-25            | 3                   | 40-49                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | 71-88 | 8   |  |     |     |  |     |     |   |       |       |   |     |       |   |       |       |   |      |       |   |       |       |   |       |       |   |       |       |   |       |       |   |     |     |   |
| 15-19    | 26-34            | 4                   | 50+                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               | 89+   | 9   |  |     |     |  |     |     |   |       |       |   |     |       |   |       |       |   |      |       |   |       |       |   |       |       |   |       |       |   |       |       |   |     |     |   |

# Care and cleaning

## Coarse filter


The coarse filter traps larger food particles, which cannot get past the drainage pump. Empty the coarse filter as necessary.



- 1 Lift the coarse filter by the handle.
- 2 Empty the coarse filter. Remember to replace it!

## Fine filter

Debris that collects on the fine filter is automatically rinsed away during each wash. Clean the fine filter when necessary.



- 1 Turn the handle anticlockwise.
- 2 Lift the filter straight up using the handle. Free the coarse filter to clean the fine filter.
- 3 Replace in reverse order. Check that the edges seal properly when replacing the fine filter.
- 4 Lock the filter in place by turning the handle clockwise to the stop position. The handle should point straight out from the dishwasher.


### NOTE!

The dishwasher must not be used without the filters in place!

Dishwashing results may be affected if the coarse filter is incorrectly fitted.

## Spray arms


Holes and bearings can sometimes become blocked. Remove any debris using a pin or the like. The spray arms also have holes underneath.



To facilitate cleaning you can remove the spray arms. Remember to fit them firmly back into place afterwards.


## Upper spray arm

- 1 Pull out the upper basket.
- 2 Unscrew the spray arm bearings counterclockwise to remove the spray arm from the upper basket.



## Lower spray arm

- Pull the lower spray arm straight up to release it.



## The door and the door seal

Regularly clean the sides of the door and the door seal. Use a slightly damp cloth (with a little cleaner if necessary).

## Front panel

Keep the buttons clean and free from grease. Wipe them clean with a dry or slightly damp cloth. Never use cleaners – they can scratch the surface. Use the main power switch to turn off the dishwasher before cleaning the buttons to avoid activating any buttons unintentionally.

## The dishwasher tub

The dishwasher tub is made of stainless steel and is kept clean through normal use.

### Limescale deposits

If you have hard water, limescale deposits may build up in the dishwasher. If this happens, run the Self-cleaning programme with two tablespoons of citric acid in the detergent compartment (with no dishes in the machine). Special dishwasher cleaners are also available on the market.


## Unblocking the drainage pump

If the dishwasher still contains water after the programme has finished, something may be blocking the drainage pump. Such items are easily removed.

- 1 Turn off the machine using the main power switch and unplug it from the wall socket.
- 2 Remove the coarse filter and the fine filter.
- 3 Scoop out the water from the dishwasher tub.
- 4 In order to inspect the drainage pump, remove the coloured stop on the right in the bottom drain.
- 5 Turn the pump wheel located behind the drainage pump stop by hand. Carefully remove any items.
- 6 Replace the drainage pump stop along with the fine and coarse filters.
- 7 Plug the machine in again.

If the dishwasher still does not start and a whirring sound is heard, the overflow protection has been activated.

- Shut off the water.
- Remove the plug from the wall socket.
- Call the service department.




#### NOTE!

Do not forget to replace the drainage pump stop.

### Unblocking the inlet hose filter

If the water supply contains small particles, the outer filter on the inlet hose may become blocked, which results in Water inlet fault.

- 1 Turn off the machine using the main power switch and unplug it from the wall socket.
- 2 Turn off the water tap.
- 3 Unscrew the inlet hose.
- 4 Carefully remove the outer filter from the inlet hose and clean it.
- 5 Replace the filter and check that the gasket is correctly positioned.
- 6 Screw the inlet hose firmly into place.
- 7 Plug the machine into the wall socket and turn on the water tap. Allow the pressure to settle for a while and check that the connection is watertight.



# Troubleshooting

| Type of fault on the display |                     | Action                                                                                                                                                                                                                                                                                                              |
|------------------------------|---------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>F10</b>                   | Overfilling water 1 | Clear the drainage pump. See the section Care and cleaning. If the problem persists, call the service department.                                                                                                                                                                                                   |
| <b>F11</b>                   | Water outlet fault  | See "Water remains in the dishwasher" in the table "Problem" below. If the problem persists, call the service department.                                                                                                                                                                                           |
| <b>F12</b>                   | Water inlet fault   | Check that the water tap is on. Check that the outer filter on the inlet hose is not blocked. See Unblocking the inlet hose filter in the chapter Care and cleaning. If the problem persists, call the service department.<br>Check that the water tap is on. If the problem persists, call the service department. |
| <b>F40</b>                   | Inlet valve leakage | Turn off the water tap and call the service department.                                                                                                                                                                                                                                                             |
| <b>F52</b>                   | Water level fault   | Call the service department.                                                                                                                                                                                                                                                                                        |
| <b>F54</b>                   | Overfilling water 2 | Turn off the water tap and call the service department.                                                                                                                                                                                                                                                             |
| <b>F56</b>                   | Circ. pump fault    | Call the service department.                                                                                                                                                                                                                                                                                        |

Press any button to clear the error message.

| Problem                                | Possible causes                                                                                                               | Action                                                                                      |
|----------------------------------------|-------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------|
| The buttons do not react when pressed. | You have pressed the buttons too soon after opening the door.                                                                 | Wait a moment then try again.                                                               |
|                                        | Child lock (button lock) activated.                                                                                           | See the section Settings.                                                                   |
|                                        | The door is closed.                                                                                                           | Open the door. The buttons only react to use when the door is open.                         |
|                                        | The buttons are dirty.                                                                                                        | Clean with a dry or slightly damp cloth.                                                    |
| Cannot close door.                     | The baskets are not correctly positioned.                                                                                     | Check that the baskets are correctly positioned horizontally.                               |
|                                        |                                                                                                                               | Check that the dishes are not blocking the baskets from sliding properly into place.        |
| The dishwasher does not start.         | The Start/Stop start button has been pressed for too short a time.                                                            | Press and hold Start/Stop until the display shows "Program started, close door".            |
|                                        | The door is not properly closed.                                                                                              | Check.                                                                                      |
|                                        | You have opened the dishwasher to add more dishes while a programme is in progress.                                           | Close the door and wait. After a while, the dishwasher continues the programme.             |
|                                        | A fuse/circuit breaker has been tripped.                                                                                      | Check.                                                                                      |
|                                        | The plug is not plugged into the wall socket.                                                                                 | Check.                                                                                      |
|                                        | The water tap is turned off.                                                                                                  | Check.                                                                                      |
|                                        | Overflow/leaks.                                                                                                               | Check.                                                                                      |
|                                        | A whirring sound (the drainage pump) is heard from the dishwasher and does not stop when the main power switch is turned off. | Turn off the water tap. Pull out the plug and call the service department.                  |
|                                        | Check that the Delayed Start option has not been selected.                                                                    | Press and hold Start/Stop for three seconds if you want to cancel the Delayed Start option. |

| Problem                                                           | Possible causes                                                                                                                       | Action                                                                                                                                         |
|-------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------|
| The dishes are not clean.                                         | The spray arms do not rotate.                                                                                                         | Check that the dishes are not blocking the spray arms.                                                                                         |
|                                                                   | Spray arm holes or bearings blocked.                                                                                                  | Clean the spray arms. See the chapter Care and cleaning.                                                                                       |
|                                                                   | Unsuitable dishwashing programme.                                                                                                     | Choose a longer programme.                                                                                                                     |
|                                                                   | Incorrect detergent dosage.                                                                                                           | Dose according to water hardness. Far too much or far too little detergent results in poorer dishwashing results.                              |
|                                                                   | Old detergent. Detergent is a perishable product.                                                                                     | Avoid large packages.                                                                                                                          |
|                                                                   | Dishes loaded incorrectly.                                                                                                            | Do not cover porcelain with large bowls or the like. Avoid placing very tall glasses in the corners of the baskets.                            |
|                                                                   | Glasses and cups have toppled over during the programme.                                                                              | Place dishes to sit steady.                                                                                                                    |
|                                                                   | The filters are not fitted correctly.                                                                                                 | Check that the filter handle is locked in the stop position. The handle should point straight out from the dishwasher.                         |
| Spots on stainless steel or silver.                               | Some foodstuffs, such as mustard, mayonnaise, lemon, vinegar, salt and dressings, can mark stainless steel if left for too long.      | Rinse off these types of foodstuffs if not starting the dishwasher immediately. Use the Rinse and hold programme.                              |
|                                                                   | All stainless steel can cause spots on silver if they come into contact during dishwashing. Aluminium can also cause spots on dishes. | In order to avoid marks and tarnishing, separate dishes made from different metals, such as silver, stainless steel and aluminium.             |
| Spots or films on the dishes.                                     | Incorrect rinse aid dosage setting.                                                                                                   | See the section Settings.                                                                                                                      |
|                                                                   | The setting TAB is activated and all-in-one detergent with insufficient drying effect is being used.                                  | Switch all-in-one detergents or deactivate the setting TAB and top up with salt and separate rinse aid. See Rinse aid in the chapter Settings. |
|                                                                   | Salt compartment empty.                                                                                                               | Top up with salt. See the section Before washing for the first time.                                                                           |
|                                                                   | Incorrect water softener setting.                                                                                                     | See Water hardness in the chapter Settings.                                                                                                    |
|                                                                   | The water softener is leaking salt.                                                                                                   | Check that the salt compartment lid is properly tightened. Otherwise call the service department.                                              |
|                                                                   | Too high temperature and/or too much detergent can cause etching on crystal. Unfortunately, this cannot be repaired, only prevented.  | Wash crystal at a low temperature and with a conservative amount of detergent. Contact the detergent manufacturer.                             |
| The dishes have a sticky white/blue film.                         | Rinse aid dosage setting too high.                                                                                                    | Reduce the dosage. See the chapter Settings. If you have very soft water, you may want to dilute the rinse aid 50:50 with water.               |
| Spots left after washing.                                         | Lipstick and tea can be difficult to wash off.                                                                                        | Use a detergent with a bleaching agent.                                                                                                        |
| Detergent residue in the detergent compartment after dishwashing. | The detergent compartment was damp when adding detergent.                                                                             | The detergent compartment must be dry when adding detergent.                                                                                   |
|                                                                   | The detergent compartment has been blocked.                                                                                           | Check that the dishes are not preventing the detergent compartment from opening.                                                               |
| Rattling sound when dishwashing.                                  | The dishes are not correctly placed or the spray arms are not rotating.                                                               | Check that the dishes are placed securely. Spin the spray arms to make sure they can rotate.                                                   |

| Problem                          | Possible causes                                                                                      | Action                                                                                                                                                                           |
|----------------------------------|------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Water remains in the dishwasher. | The filters are blocked.                                                                             | Clean the coarse and fine filters.                                                                                                                                               |
|                                  | The filters are not fitted correctly.                                                                | Check that the filter handle is locked in the stop position. The handle should point straight out from the dishwasher.                                                           |
|                                  | Debris in the drainage pump.                                                                         | Clean the drainage pump. See the section Care and cleaning.                                                                                                                      |
|                                  | Kink in drainage hose.                                                                               | Check that the hose is free from kinks and sharp bends.                                                                                                                          |
|                                  | Blocked drainage hose.                                                                               | Disconnect the drainage hose where it connects to the sink unit's water trap. Check that no debris has fastened and that the connection has an inner diameter of at least 14 mm. |
| Bad odour in dishwasher.         | Dirt around the seals and in corners.                                                                | Clean with washing-up brush and low foaming cleaner.                                                                                                                             |
|                                  | Low temperature programmes have been selected for a prolonged period.                                | Run a programme with a higher temperature once or twice a month. Or run a self-cleaning programme. See Self-cleaning in the chapter Using the dishwasher.                        |
| The dishes are not dry enough.   | Depending on the load, the programme's drying cycle may be insufficient.                             | Activate the Extra Dry option.                                                                                                                                                   |
|                                  | The dishwasher is not fully loaded.                                                                  | Fully load the dishwasher.                                                                                                                                                       |
|                                  | Rinse aid needs topping up or dosage is set too low.                                                 | Top up with rinse aid or increase the rinse aid dosage level. See the chapter Settings.                                                                                          |
|                                  | The setting TAB is activated and all-in-one detergent with insufficient drying effect is being used. | Switch all-in-one detergents or deactivate the setting TAB and top up with salt and separate rinse aid. See Rinse aid in the chapter Settings.                                   |
|                                  |                                                                                                      | Open the door a little once the programme has finished.                                                                                                                          |

# Technical information

## Information on energy labelling

Information sheet, in compliance with Commission Delegated Regulation (EU) No. 1059/2010

### ATAG

|                                                                     |                                     |
|---------------------------------------------------------------------|-------------------------------------|
| Model designation:                                                  | VA7015QT                            |
| Number of standard place settings:                                  | 13 <sup>1)</sup>                    |
| Energy efficiency class:                                            | A+++                                |
| Annual energy consumption(AE <sub>C</sub> ):                        | 234 kWh per year <sup>2)</sup>      |
| Energy consumption of the standard cleaning cycle(E <sub>t</sub> ): | 0.82 kWh                            |
| Power consumption                                                   |                                     |
| Off-mode (P <sub>o</sub> ):                                         | 0.49 W                              |
| Left-on mode (P <sub>l</sub> ):                                     | 0.49 W                              |
| Annual water consumption (AW <sub>C</sub> ):                        | 3556 litres per year <sup>3)</sup>  |
| Drying efficiency class:                                            | A <sup>4)</sup>                     |
| Standard programme:                                                 | ECO wash <sup>5)</sup> , no options |
| Programme time for the standard cleaning cycle:                     | 310 minutes                         |
| Duration of the left-on mode (T <sub>l</sub> ):                     | Infinite                            |
| Noise emissions:                                                    | 44 dB(A) re 1 pW                    |
| Construction:                                                       | Integrated product                  |

<sup>1)</sup> In accordance with standard, EN 50242.

<sup>2)</sup> Based on 280 standard cleaning cycles with a cold water connection and consumption in accordance with energy saving mode. The actual energy consumption depends on how the machine is used.

<sup>3)</sup> Based on 280 standard cleaning cycles. The actual water consumption depends on how the machine is used.

<sup>4)</sup> On a scale from G (least efficient) to A (most efficient).


<sup>5)</sup> This dishwashing programme is the standard cleaning cycle used to compile the energy labelling information. It is intended for washing normally dirty dishes and is the most effective programme in terms of combined energy and water consumption.

## Technical data

|                        |                         |
|------------------------|-------------------------|
| Height:                | 819-872 mm              |
| Width:                 | 596 mm                  |
| Depth:                 | 559 mm                  |
| Weight:                | 50 kg <sup>1)</sup>     |
| Water pressure:        | 0.03–1.0 MPa            |
| Electrical connection: | See serial number plate |
| Rated power:           | See serial number plate |

<sup>1)</sup> Weight can vary due to different specifications.

# Installation



It is important that you read through and follow the instructions and directions below. Conduct installation and connection in accordance with the separate installation instructions.

## Safety instructions

- Connections to electricity, water and drainage must be performed by a qualified professional.
- Always follow applicable regulations for water, drainage and electricity.
- Take care during installation! Wear protective gloves! There must always be two people!
- Place a drip tray on the floor beneath the dishwasher to prevent damage from any water leaks.
- Before screwing the dishwasher into place, test the dishwasher by running the Rinse and hold programme. Check that the dishwasher fills with water and drains. Check also that none of the connections leak.

### ⚠ WARNING!

Turn off the water supply when installing the dishwasher!

The plug must be disconnected or power to the socket turned off while the work is carried out!

## Setup

- The recess and connection dimensions are included in the separate installation instructions. Check that all dimensions are correct before starting the installation. Note that the height of the cover door can be adjusted to match other fittings.
- Make sure the area on which the dishwasher is to be installed is firm. Adjust the adjustable feet so that the dishwasher is level. Tighten the lock nuts.

## Drainage connection

See the separate installation instructions for necessary information.

This dishwasher is suitable for installing in a raised recess (to attain an ergonomic working height). This means that the dishwasher can be placed so that the drainage hose runs to a lower level than the bottom of the dishwasher, such as by routing it directly to a floor drain. The dishwasher is fitted with an integrated anti-siphon device to prevent the machine from being emptied of water during the wash cycle.

The drainage hose can also be connected to a connection nipple on the sink unit's water trap. The connection nipple must have an internal diameter of at least 14 mm.

The drainage hose may be extended by a maximum of 2.5 m (the total length of the drainage hose must not exceed 4.5 m). Any joints and connecting pipes must have an internal diameter of at least 14 mm. However, the drainage hose should ideally be replaced with a new hose without joints.

No part of the drainage hose may be more than 950 mm above the bottom of the dishwasher.

Ensure that the drainage hose has no kinks.

## Connection to water supply

Use only the inlet hose supplied with the dishwasher. Do not re-use old or other spare hoses.

The supply pipe must be fitted with a water tap (stopcock). The water tap must be easily accessible, so that the water can be shut off if the dishwasher has to be moved.

Once the installation is complete, turn on the water tap and allow the pressure to settle for a while. Check that all connections are watertight.

### Connection to cold water supply

Connect the dishwasher to the cold water supply if the building is heated using oil, electricity or gas.

### Connection to hot water supply

Connect the dishwasher to the hot water supply (max. 70 °C) if the building is heated using an energy-efficient means such as district

heating, solar power or geothermal power. Choosing a hot water connection cuts dishwashing times and reduces the dishwasher's energy consumption.

## NOTE!

Do not exceed the permitted water supply temperature. Certain materials used in some cookware cannot withstand strong heat. See Fragile dishes in the chapter Loading the dishwasher.

## Electrical connection

Information about the electrical connection can be found on the serial number plate. This specification must match the electricity supply.

The dishwasher must be connected to an earthed socket.


The electric wall socket must be placed outside of the installation area to be easily accessible after installing the dishwasher. Do not use an extension cord!

## NOTE!

Repairs and maintenance relating to safety or performance must be carried out by a qualified professional.

Read the chapter Troubleshooting before contacting the service department. If you have encountered a problem that you cannot resolve, please contact your nearest dealer.


When making contact, provide the details on the serial number plate. Include the article number (1) and the serial number (2).



# Information for test institute

Request test institute information via e-mail  
[dishwashers@appliance-development.com](mailto:dishwashers@appliance-development.com).

The request should include the details on the serial number plate.  
Include the article number (1) and the serial number (2).




## Your notes

[illegible]

# Quick guide

1.




## Load the baskets

(See page 6.)

Do not rinse dishes under running water before loading them in the dishwasher. Simply scrape off large food particles before loading the dishwasher.

2.




## Check that the spray arms can rotate freely

Check also that the water tap is on.

Don't forget! Empty the course filter and clean the fine filter when necessary. (See page 14.)


3.



## Add detergent

The detergent compartment has one smaller compartment for the prewash and one for the main wash. (See page 8.)

4.



## Press and hold the main power switch until the display lights up

5.




## Check/Add rinse aid and salt

Top up salt and rinse aid to achieve good washing and drying results. (See page 4.)

💧 Top up rinse aid

⚙️ Top up salt

6.



## Select a programme, programme mode and any options

(See page 9.)

7.



## Press Start/Stop, close the door

# ATAG

[www.atag.nl](http://www.atag.nl)



en (01-18)

687669

