Problem	Possible causes	What to do
F3-F8	Temperature sensor failure	Please contact the supplier.
F9-FE	Temperature sensor of the	Please contact the supplier.
	IGBT failure.	
E1/E2	Abnormal supply voltage	Please inspect whether power
		supply is normal.
		Power on after the power
		supply is normal.
E3/E4	Abnormal temperature	Please inspect the pot.
E5/E6	Bad induction hob heat	Please restart after the
	radiation	induction hob cools down.

Failure	Problem	Solution A	Solution B
The LED does not	No power supplied.	Check to see if plug is	
come on when unit is		secured tightly in outlet	
plugged in.		and that outlet is working.	
	The accessorial power	Check the connection.	
	board and the display		
	board connected failure		
	The accessorial power	Replace the accessorial	
	board is damaged.	power board	
	The display board is	Replace the display	
	damaged.	board.	
Some buttons can't work,	The display board is	Replace the display	
or the LED display is not	damaged.	board.	
normal.			
The Cooking Mode	High temperature of the	Ambient temperature	
Indicator comes on, but	hob.	may be too high.Air	
heating does not start.		Intake or Air Vent may be	
		blocked.	
	There is something wrong	Check if the fan runs	
	of the fan.	smoothly.Fan should be	
		replaced by a new one if	
		not work anymore.	
	The power board is	Replace the power board.	
	damaged.		

Failure	Problem	Solution A	Solution B
Heating stops suddenly	Pan Type is wrong.	Use the proper pot (refer	Pan detection circuit is
during operation and	Pot diameter is too small	to the instruction manual.)	damaged, replace the
display " <u>u</u> ".	Cooker has overheated;	Unit is overheated.Wait	power board.
		for temperature to return	
		to normal.	
		Push "ON/OFF" button to	
		restart unit.	
Heating zones of the	The power board and the	Check the connection.	
same side (Such as the	display board connected		
first and the second	failure;		
zone) would display " <u>u</u> " .	The display board of	Replace the display	
	communicate part is	board.	
	damaged.		
	The power board is	Replace the power board.	
	damaged.		
Fan motor sounds	The fan motor is	Replace the fan.	
abnormal.	damaged.		