



EN

# **User manual**

## Dishwasher

VW942HN

# Contents


|  |           |
|--|-----------|
| <b>Your dishwasher</b> .....                   | <b>4</b>  |
| <b>Safety instructions</b> .....               | <b>5</b>  |
| Installation .....                             | 6         |
| Overflow guard function .....                  | 6         |
| Winter storage/transport .....                 | 6         |
| Packaging .....                                | 6         |
| Disposal .....                                 | 6         |
| <b>Before washing for the first time</b> ..... | <b>7</b>  |
| Water hardness .....                           | 7         |
| Basic settings .....                           | 8         |
| Top up with rinse aid .....                    | 8         |
| Top up with salt .....                         | 8         |
| <b>Greener dishwashing</b> .....               | <b>9</b>  |
| Save energy and water .....                    | 9         |
| <b>Loading the dishwasher</b> .....            | <b>10</b> |
| Fragile dishes .....                           | 10        |
| Loading affects the results .....              | 10        |
| The dishwasher's baskets .....                 | 10        |
| Top cutlery tray .....                         | 10        |
| Upper basket .....                             | 11        |
| Lower basket .....                             | 12        |
| <b>Using the dishwasher</b> .....              | <b>13</b> |
| Add detergent .....                            | 13        |
| On/Off .....                                   | 14        |
| Select program .....                           | 14        |
| Select option .....                            | 15        |
| Start/Stop .....                               | 16        |
| Status light .....                             | 16        |
| If you want to load more dishes .....          | 16        |
| Power failure .....                            | 17        |
| Once the program has finished .....            | 17        |
| The best drying results .....                  | 17        |
| Unloading the dishwasher .....                 | 17        |
| <b>Program chart</b> .....                     | <b>18</b> |
| <b>Settings</b> .....                          | <b>19</b> |
| <b>Care and cleaning</b> .....                 | <b>21</b> |
| Top up with rinse aid .....                    | 21        |
| Top up with salt .....                         | 21        |
| Clean the filters .....                        | 22        |
| Cleaning the spray arms .....                  | 23        |
| Clean the outside of the dishwasher .....      | 24        |
| <b>CLn</b> - Run the Self-clean program .....  | 24        |
| Remove blockages .....                         | 24        |
| <b>Troubleshooting</b> .....                   | <b>26</b> |

|  |           |
|--|-----------|
| <b>Installation .....</b>                        | <b>31</b> |
| Safety instructions .....                        | 31        |
| Setup .....                                      | 31        |
| Drainage connection .....                        | 32        |
| Connection to water supply .....                 | 32        |
| Electrical connection .....                      | 33        |
| <b>Service .....</b>                             | <b>34</b> |
| <b>Technical data and energy labelling .....</b> | <b>35</b> |
| Technical data .....                             | 35        |
| Information for consumers .....                  | 35        |
| Information for test institute .....             | 35        |

# Your dishwasher

Install the dishwasher, see the chapter *Installation*. Then open the door and press ①.

The first time the dishwasher is switched on, it is important that you choose the right settings to ensure good dishwashing results. See the chapter *Before washing for the first time*.



## Program

- Auto 45-65°
- Eco Eco 55°
- 1h 65°
- Intensive 70°
- Glass 40°
- Hygiene 70°
- Night 55°
- Quick 35°

## Option

- Delayed start
- Speed wash
- Automatic door opening

## Special program

- Self-clean

## Information on the display

See the chapter *Care and cleaning*.

Top up with rinse aid

Top up with salt

**CLn** Run the Self-clean program

## NOTE!

The control panel only reacts to use when the door is open.

## Safety instructions

- Read the operating instructions and keep them in a safe place!
- Number of standard place settings: 16
- Never use the dishwasher for any purpose other than that specified in these operating instructions.
- Do not load the dishwasher door or dishwasher baskets with anything other than dishes.
- Never leave the dishwasher door open as someone may trip on it. Push the baskets in to avoid risking the dishwasher tipping over.
- Use only dishwasher detergent!
- This machine can be used by children aged 8 and upwards, and by people with reduced physical capacity, mental ability, memory loss or lacking experience and knowledge. These individuals must be supervised when using the machine or have instructions on how to use the machine and understand the risks that can occur. Cleaning of the machine must not be carried out by children without supervision.
- Damaged supply cord must only be replaced by the manufacturer's service centre or someone similarly professionally qualified.
- Only use the dishwasher in household-type environments for dishwashing household dishes. All other use is prohibited.
- Never place dishes with solvent residues in the dishwasher due to the risk of explosion. Nor may dishes that contain ash, wax or lubricants be washed in the dishwasher.
- Children must be watched. Do not allow children to use or play with the dishwasher. Be especially vigilant when the door is open. Some detergent may remain inside! After adding detergent, always start the dishwasher immediately.



### WARNING!

Knives and other pointed items must be placed horizontally in the dishwasher's special cutlery baskets.

**WARNING!**

Children must be supervised – dishwasher detergent is corrosive!

## Installation

See the chapter *Installation*.

## Overflow guard function

The overflow guard starts pumping out the machine and turns off the water supply if the water level in the dishwasher exceeds the normal level. If the overflow guard is triggered, F54 (Overfilling water) appears on the display. Turn off the water tap and contact your nearest service centre. (To avoid water leakage outside the dishwasher, do not remove the plug from the wall socket until the water tap on the supply line has been turned off!)

## Winter storage/transport

Store the dishwasher above freezing and avoid long transport distances in very cold weather. Transport the dishwasher upright or laying on its back.

Before transporting a used dishwasher, or before prolonged storage, water must first be removed from the machine.

## Packaging

The outer packaging protects the product during transport. The packaging material is recyclable. Separate the different packaging materials to help reduce raw material use and waste. Your dealer can take the packaging for recycling or direct you to the nearest recycling centre. The packaging is comprised of:

- Corrugated cardboard made from up to 100% recycled material.
- Expanded polystyrene (EPS) with no added chlorine or fluorine.
- Supports made from untreated wood.
- Protective plastic made from polyethylene (PE).

## Disposal

The dishwasher is manufactured and labelled for recycling. When the dishwasher has reached the end of its service life and is to be disposed of, it should immediately be made unusable. Pull out the power cable and cut it as short as possible. Remove the light source/light sources.

Contact your local authority for information about where and how your dishwasher should be correctly recycled.

# Before washing for the first time

## Water hardness

In order to achieve good dishwashing results, the dishwasher needs soft water (water with low mineral content). Hard water leaves a white coating on dishes and the dishwasher.

## Checking water hardness

Water hardness is specified using German degrees of water hardness (°dH), French degrees of water hardness (°fH), English degrees of water hardness (°eH) or millimoles per litre (mmol/l).

A water supply with a water hardness in excess of 5°dH (9°fH / 6°eH / 0.9 mmol/l) must be softened. This is done automatically with the aid of the built-in water softener. In order for the water softener to function properly, its settings must be adjusted to the hardness of the water supply. Once you have adjusted the water softener settings, add detergent and rinse aid in doses suitable for soft water.

Contact the local waterworks to check the water hardness in your area.

Make a note of the water hardness: \_\_\_\_\_

| °dH   | °fH   | °eH   | mmol/l  | Recommended setting |
|-------|-------|-------|---------|---------------------|
| 0-5   | 0-9   | 0-6   | 0.0-0.9 | 00                  |
| 6-8   | 10-14 | 7-10  | 1.0-1.4 | 01                  |
| 9-11  | 15-20 | 11-14 | 1.5-2.0 | 02                  |
| 12-14 | 21-25 | 15-18 | 2.1-2.5 | 03                  |
| 15-19 | 26-34 | 19-24 | 2.6-3.4 | 04                  |
| 20-24 | 35-43 | 25-30 | 3.5-4.3 | 05                  |
| 25-29 | 44-52 | 31-36 | 4.4-5.2 | 06                  |
| 30-39 | 53-70 | 37-49 | 5.3-7.0 | 07                  |
| 40-49 | 71-88 | 50-61 | 7.1-8.8 | 08                  |
| 50    | 89    | 62    | 8.9     | 09                  |

If the water hardness exceeds 50°dH (89°fH / 62°eH / 8.9 mmol/l), we recommend connecting an external water softener.

## Increased consumption during regeneration

The dishwasher's built-in water softener is regularly regenerated to maintain its function. Regeneration extends the dishwashing program and increases energy and water consumption. Just how often the dishwasher's water softener is regenerated depends on the selected setting.

Example: If the Eco 55° program is run with a water hardness of 14°dH (25°fH / 18°eH / 2.5 mmol/l), the water softener is regenerated at regular intervals (after 7 dishwashing cycles), energy consumption increases by 0.015 kWh, and water consumption increases by 2.3 litres, while the program time is extended by 3 minutes. Regeneration takes place during the program's main wash.

### **WARNING!**

Hard water leaves a white coating on dishes and inside the dishwasher. It is therefore important that you select the right setting for the water softener! See Water hardness in the chapter *Settings*.

Never run the dishwasher with an empty salt compartment if the water supply has a water hardness in excess of 5°dH (9°fH / 6°eH / 0.9 mmol/l).

## Basic settings

The first time the dishwasher is switched on, it is important that you choose the right settings to ensure good dishwashing results. See the chapter *Settings*.


Set up:

- Rinse aid
- Water hardness
- TAB

### ✳ Top up with rinse aid

Drying is faster and a better result is achieved if you use rinse aid. You will also achieve a better dishwashing result with clear and spotless dishes.


Top up the rinse aid compartment with rinse aid if you have selected Rinse aid 01 - 05.



1. Open the rinse aid compartment lid.
2. Carefully top up with rinse aid to the level marked **MAX**.
3. Wipe up any splashes of rinse aid around the compartment.
4. Close the lid firmly.

### ☞ Top up with salt

Add salt to the salt compartment if you have selected Water hardness 01 - 09.



1. Remove the salt compartment lid by turning it anticlockwise.
2. Place the funnel supplied with the dishwasher in the salt compartment top-up hole. First, pour in about 1 l of water.
3. Add enough salt to fill the salt compartment (max. 750 gram). Use special dishwasher salt.
4. Wipe up any excess salt so that the lid can be screwed on firmly.

### ⚠ WARNING!

In order to avoid rust stains a dishwashing program must be started immediately after adding salt.



# Greener dishwashing

## Save energy and water

When using a dishwasher in a residential setting, less energy and water are generally used compared to washing the dishes by hand.

### Do not rinse under running water



Do not rinse the dishes under running water as this will lead to increased energy and water consumption. Simply scrape off large food particles before loading the dishwasher.

### Choose a green detergent

Read the environmental declaration on the packaging!

Too much detergent, rinse aid and salt can result in less effective dishwashing and also entail greater environmental impact.

### Run a fully loaded dishwasher

Save energy and water by waiting until the dishwasher is full before running a program (see number of standard place settings). Use the  1h 65° program with the  Speed wash option to rinse the dishes if there are any unpleasant odours.

### Run programs at a lower temperature


If the dishes are only slightly dirty, you can select a program with a low temperature.

### Select dishwashing program – Eco 55°

This program is suitable for washing normally soiled dishes and is the most effective program in terms of combined energy and water consumption. This program is used to assess compliance with EU legislation on ecodesign.

The dishwashing program is designed for an effective wash using as little energy and water as possible. The program washes at a low temperature for a long time.

### Select option – Automatic door opening

A shorter dishwashing program and better drying results are achieved if you use the  Automatic door opening option, which automatically opens the dishwasher door. Wait until the dishwasher indicates that the program has ended and the dishes have cooled before unloading the dishwasher. (If the dishwasher is built-in, the surrounding furnishings must be resistant to any condensation from the dishwasher.)

### Connect to cold water

Connect the dishwasher to the cold water supply if the building is heated using oil, electricity or gas.

### Connection to hot water supply

Connect the dishwasher to the hot water supply (max. 70 °C) if the building is heated using an energy-efficient means such as district heating, solar power or geothermal power. Choosing a hot water connection reduces the dishwasher's energy consumption.

### NOTE!

Do not exceed the permitted water supply temperature. Certain materials used in some cookware cannot withstand high heat. See *Fragile dishes* in the chapter *Loading the dishwasher*.

# Loading the dishwasher

## Fragile dishes

Some cookware is not dishwasher safe. This can be for several reasons. Some materials cannot withstand high heat, others can be damaged by dishwasher detergent.

Exercise caution with, for example, handmade items, fragile decoration, crystal/glassware, silver, copper, tin, aluminium, wood and plastic. Look for the "Dishwasher safe" marking.

## Loading affects the results

Load the dishes carefully to ensure the best washing and drying results with the lowest possible energy and water consumption. Give your dishwasher the best chance to reach and clean all surfaces, as well as to dry the dishes as thoroughly as possible.

- All dirty surfaces should face inwards and downwards!
- Dishes should not be placed in or on each other.
- Angle dishes with hollows, such as cups, so that the rinse water will run off. This is also important for plastic items.
- Make sure small items cannot fall through the dishwasher basket; place them in the top cutlery tray.



### NOTE!

Check that the spray arms can rotate freely.



## The dishwasher's baskets

The dishwasher is equipped with a top cutlery tray, an upper basket and a lower basket.

*The appearance of the baskets may differ depending on the dishwasher setup.*

## Top cutlery tray



The top cutlery tray has space for cutlery, ladles, whisks, serving cutlery and similar items.




The top cutlery tray is comprised of three parts that can be moved sideways to better accommodate the dishes.

## Upper basket

Place glasses, cups, bowls, side plates and saucers in the upper basket. All dirty surfaces should face inwards and downwards! Wine glasses are placed on the wine glass shelf and knives are placed in the knife stand on the right.




Knife stand



3 positions


## Raising and lowering the upper basket

1. Pull out the upper basket.
2. Grab the sides of the upper basket with both hands and lift it up.
3. If the upper basket is raised while in the top position, it will drop to the bottom position.  
Note that both sides of the basket must always be set to the same height.





### Adjustable plate supports

The adjustable plate supports can be folded down to make it easier to load pots, bowls and glasses.



### Lower basket


Place plates, side plates, serving dishes and pots in the lower basket. Cutlery can be placed in the cutlery holder.



Fit the cutlery holder to achieve maximum loading capacity. (Found inside the enclosed plastic bag.)

### Adjustable plate supports

The adjustable plate supports can be folded down to make it easier to load pots and bowls.



# Using the dishwasher


## Add detergent

Follow the instructions on the detergent packaging. This dishwasher is fitted with a water softener, so use detergent and rinse aid doses suitable for soft water.

Too much detergent can result in less effective dishwashing and also entails greater environmental impact.

### Detergent compartment

The detergent compartment must be dry when adding detergent.



If powder or liquid dishwasher detergent is used, add a small amount of the detergent to the compartment for prewash detergent.

### NOTE!

Use only dishwasher detergent! Washing up liquid must not be used as the foam that forms prevents the dishwasher from operating effectively.

### All-in-one detergent

There are many types of all-in-one detergents on the market. Read through the directions for these products carefully.

Activate the TAB setting and deactivate the Rinse aid setting, when using an all-in-one detergent that contains rinse aid.

Dishwasher tablets are not recommended for short programs (less than 75 minutes). Use powder or liquid dishwasher detergent instead.


### NOTE!

Optimal washing and drying results are achieved by using normal detergent together with separately dispensed rinse aid and salt.

Contact the detergent manufacturer if you have questions about the detergent.

On/Off

Start/Stop



Display



## NOTE!

The control panel only reacts to use when the door is open.

## ① On/Off

Open the door and press ①. Also turn on the water tap if it is turned off.

## Select program

Select a program to suit the type of dishes and how dirty they are. Eco 55° is always pre-selected.

Press the desired program until it is activated, which is indicated by an indicator light.



### Auto 45-65°

The dishwasher can measure how dirty the dishes are and adjust water consumption and temperature accordingly. When newly installed, the program needs to be run five times before it is fully adapted and can provide the best results.

### Eco Eco 55°

This program is suitable for washing normally soiled dishes and is the most effective program in terms of combined energy and water consumption. This program is used to assess compliance with EU legislation on ecodesign.

You can read more about greener dishwashing in the chapter *Greener dishwashing*.

For heavily soiled dishes with a lot of grease, a program with higher temperatures should be used.



### 1h 65°

A quick program for slightly dried leftovers. (This program is not intended for burnt food, such as on oven dishes.)

The Automatic door opening option is important for ensuring the best drying results.



### Intensive 70°

A program with a high temperature for dissolving grease on very dirty dishes, such as pans, casserole dishes and oven dishes. If these dishes do not completely fill the dishwasher, you can add plates and other dishes.



### Glass 40°

A gentle dishwashing program with a low temperature for washing fragile items made of crystal/glass. Remember to use a small amount of detergent and to place items so that they do not touch each other during the wash. See also *Fragile dishes* in the chapter *Loading the dishwasher*. Porcelain that has just been used without dried leftovers can also be washed using this program.



## Hygiene 70°

This program is ideal to use where demands on hygiene are extra high, e.g. for baby bottles and cutting boards. The temperature is high both in the main wash and in the final rinse.



## Night 55°

A quieter dishwashing program, suitable for running at night. The program time is extended.



## Quick 35°

A quick program for dishes that have just been used and have no dried leftovers on them.



## Self-clean

Self-cleaning program for hygienic cleaning of the dishwasher tub, spray arms and spray pipes.

This program should be run (with no dishes in the machine) using normal dishwasher detergent or citric acid. Special dishwasher cleaners are also available on the market. For the removal of limescale deposits, see *Dishwasher tub* in the chapter *Care and cleaning*.

The dishwasher will indicate at regular intervals that Self-clean needs to be run.

## Select option

Press the options to activate them. (The available options vary between programs.)



## Delayed start

When you select Delayed start, the dishwasher will start 1-24 hours after you have pressed  $\triangleright|$  and closed the door.

1. Press  $\odot$  once to activate Delayed start. Press several times, or hold it in, to set the desired number of hours. The time for Delayed start is shown on the display.
2. Press  $\triangleright|$ . Close the door. The timer counts down and the dishwasher starts after the selected delay.

If you want to cancel the Delayed start option, open the door then press and hold  $\triangleright|$  for three seconds.

*Not available for: Self-clean*



## Speed wash

This option shortens the program time, but uses more energy and water.

Press  $\odot$  to activate the option. The program time is updated on the display.

*Not available for: Auto 45-65°, Glass 40°, Hygiene 70°, Quick 35°, Self-clean*



## Automatic door opening

The dishwasher door opens automatically, which shortens the program time and improves the drying results. Wait until the dishwasher indicates that the program has ended and the dishes have cooled before unloading the dishwasher. (If the dishwasher is built-in the surrounding furnishings must be resistant to any condensation from the dishwasher.)

The drying time of the Automatic door opening option varies (from 5 to 90 minutes) depending on the model, program and temperature of the final rinse.

Press  $\square$  to activate the option, which is indicated by an indicator light.

The Automatic door opening option is pre-selected for some programs.

*Not available for: Hygiene 70°, Self-clean*


### **NOTE!**

For the best drying results, do not close the door before the drying phase has finished and the machine has automatically switched off.


### **WARNING!**


The dishwasher door must not be blocked or closed when opened automatically. Doing so may damage the door lock mechanism. Wait at least 5 minutes before closing the door.

## **Start/Stop**

Press . The display will start to flash, indicating that the dishwasher is ready to start. Close the door properly, otherwise the dishwasher will not start.

### **Stopping or changing a program**

Open the door. If you want to interrupt or change the program after starting the dishwasher, press and hold  for three seconds.

Top up with new detergent if the lid of the detergent dispenser has opened. Then select a new program, press  and close the door.

### **Remaining time**


Once you have chosen a program and options, the time the program took when last used is displayed.

## **Status light**

The status light on the bottom part of the dishwasher indicates that a program has started.

### **Flashing light**

A flashing light indicates that the door has been opened while a program is in progress. If it flashes when the door is closed, an error has occurred. See the chapter *Troubleshooting*.



## **If you want to load more dishes<sup>1)</sup>**

Open the door. The dishwasher stops automatically. Add the dishes and close the door. After a while, the dishwasher continues the program.

<sup>1)</sup> You should not load more dishes if the lid of the detergent dispenser has been opened.



## Power failure

If the dishwasher is turned off due to a power failure when a dishwashing program is running, the program continues when power is restored. If the power is cut during drying, the program is interrupted.

If the door is open for more than 2 minutes during drying, the program is interrupted.

## Once the program has finished


The end of the program is indicated by one short signal from the buzzer. The chapter *Settings* describes how to change this function.

Moreover, the end of the program is indicated by the status light turning off.

Once the dishwasher door is opened and the program has finished "End" appears on the display.

The dishwasher switches off automatically after the program ends. Shut off the water tap after each use.

## The best drying results











- Fully load the dishwasher.
- Angle dishes with hollows, such as cups, so that the rinse water will run off. This is also important for plastic items.
- Top up with rinse aid or increase the rinse aid dosage setting.
- Activate the  Automatic door opening option.
- Open the door a little once the program has finished.
- Allow the dishes to cool before unloading the dishwasher.

## Unloading the dishwasher

Hot porcelain is more fragile. Leave the dishes to cool in the dishwasher before unloading them.

Unload the lower basket first to avoid any water drops from the upper basket falling onto the dishes in the lower basket.

# Program chart


| Program   | Detergent (ml) | Option  | Number of pre-washes | Main wash | Number of rinses | Final rinse | Consumption values <sup>1)</sup>   |                      |                     |
|---|----------------|---|----------------------|-----------|------------------|-------------|------------------------------------|----------------------|---------------------|
|   |                |   |                      |           |                  |             | Dishwashing time (approx. hrs:min) | Energy (approx. kWh) | Water cons. (liter) |
|  Auto 45-65°   | 25             |  <sup>3)</sup> | 1-2                  | 45-65 °C  | 2-3              | 60 °C       | 2:10-3:10                          | 0.9-1.4              | 11.5-19.0           |
| Eco Eco 55° <sup>2)</sup>   | 25             |  <sup>3)</sup> |                      | 55 °C     | 2                | 47 °C       | 3:20                               | 0.76                 | 9.6                 |
|  1h 65°        | 25             |  <sup>3)</sup> |                      | 65 °C     | 3                | 65 °C       | 1:00                               | 1.1                  | 15.0                |
|  Intensive 70° | 25             |   | 2                    | 70 °C     | 2                | 70 °C       | 2:50                               | 1.6                  | 16.0                |
|  Glass 40°     | 20             |   |                      | 40 °C     | 2                | 50 °C       | 1:40                               | 0.7                  | 10.0                |
|  Hygiene 70°   | 25             |   | 2                    | 70 °C     | 2                | 70 °C       | 1:05                               | 1.3                  | 11.0                |
|  Night 55°     | 25             |   | 1                    | 55 °C     | 2                | 65 °C       | 5:35                               | 1.4                  | 14.0                |
|  Quick 35°     | 10             | Automatic door opening  |                      | 35 °C     | 2                | 30 °C       | 0:20                               | 0.3                  | 10.0                |



<sup>1)</sup> Consumption values vary depending on the temperature of the incoming water, room temperature, load size, selected additional functions and more. The values for the Eco 55° program are accurate, others are indicative only.


<sup>2)</sup> This program is suitable for washing normally soiled dishes and is the most effective program in terms of combined energy and water consumption. This program is used to assess compliance with EU legislation on ecodesign.

<sup>3)</sup> Automatic door opening

# Settings

Open the door and press .

To open the dishwasher's settings menu, press and hold  and  until SET is shown on the display.

Use  to step through the menu.



To exit the menu, step through it or press .


| Settings         | Alternatives        |  |
|------------------|---------------------|--|
| 2 Sounds         | 00 - 03             | A beep confirms that the control panel has been pressed. A beep indicates when a dishwashing program has ended.<br><i>Error messages are always indicated by a loud buzzer.</i>  |
| 3 Rinse aid      | 00 - 05             | Setting for rinse aid dosage. The rinse aid dispenser can be adjusted between 00 (Off) and 05 (High dosage). Increase the rinse aid dosage: <ul style="list-style-type: none"> <li>If the dishes have water marks.</li> </ul> Decrease the rinse aid dosage: <ul style="list-style-type: none"> <li>If the dishes have a sticky white/blue film.</li> <li>If the dishes are streaked.</li> <li>Build-up of foam. If you have very soft water, the rinse aid can be diluted 50:50 with water.</li> </ul> <i>Pre-selected at factory: 04</i> |
| 4 Water hardness | 00 - 09             | Adjusting the water softener. Select a setting depending on the hardness of the water supply. It is important that this setting is correct!<br><i>See Water hardness in the chapter Before washing for the first time.</i><br><i>For a water supply with a hardness below 6°dH (10°FH / 7°eH / 1.0 mmol/l), select 00. The water softener is deactivated and no salt needs to be added.</i><br><i>Pre-selected at factory: 04</i>  |
| 5 TAB            | 00 (Off)<br>01 (On) | Activate this setting when using an all-in-one detergent that contains rinse aid.<br>This setting reduces the rinse aid dosage and affects how often the dishwasher's built-in softener is regenerated.  |

| Settings   |  | Alternatives        |  |
|------------|--|---------------------|--|
|            |  |                     | <i>Pre-selected at factory: 00</i>   |
| <b>8</b>   | Interior light when the dishwasher is switched off | 00 (Off)<br>01 (On) | Select whether the interior light is to be switched on when the dishwasher is turned off and the door is opened. (If the dishwasher is turned on, the interior light is always switched on when the door is opened.) |
| <b>F--</b> | Error readout                                      |                     | Any error messages.<br><i>When contacting the service department, you may be asked to provide the most recent error messages.</i>  |
| <b>rSt</b> | Restore factory defaults                           |                     | Restores all settings to the factory defaults.<br>Select rSt and press ▶□.   |
| <b>End</b> | Exit   |                     | To exit the dishwasher's settings menu, select End and press Ⓜ.  |

# Care and cleaning

## ✨ Top up with rinse aid

When the rinse aid needs topping up, the above symbol lights on the display.




1. Open the rinse aid compartment lid.
2. Carefully top up with rinse aid to the level marked **MAX**.
3. Wipe up any splashes of rinse aid around the compartment.
4. Close the lid firmly.

After topping up, it may take a while before the symbol goes out.

## ⊞ Top up with salt

When the salt needs topping up, the above symbol lights on the display.



1. Remove the salt compartment lid by turning it anticlockwise.
2. Place the funnel supplied with the dishwasher in the salt compartment top-up hole. (Water is only needed the first time.)
3. Add enough salt to fill the salt compartment (max. 750 gram). Use special dishwasher salt.
4. Wipe up any excess salt so that the lid can be screwed on firmly.

After topping up, it may take a while before the symbol goes out.



### **WARNING!**


In order to avoid rust stains a dishwashing program must be started immediately after adding salt.

Never pour dishwasher detergent into the salt compartment. This destroys the water softener!

# Clean the filters

## Coarse filter


The coarse filter traps larger food particles, which cannot get past the drainage pump. Empty the coarse filter when necessary. It should be cleaned at regular intervals depending on how often the dishwasher is used.



1. Lift the coarse filter by the handle.
2. Empty the coarse filter.
3. Refit the coarse filter. Press it down until it clicks into place.

## Fine filter

Debris that collects on the fine filter is automatically rinsed away during each wash. Clean the fine filter when necessary. It should be cleaned at regular intervals depending on how often the dishwasher is used.




1. Turn the locking ring anticlockwise and lift the fine filter straight up.
2. Clean the fine filter.
3. Refit the fine filter and turn the locking ring clockwise to its stop position. Check that the edges seal properly.

Remember to refit the coarse filter!


## NOTE!

Dishwashing results may be affected if the coarse and fine filters are incorrectly fitted. The dishwasher must not be used without the filters in place!



## Cleaning the spray arms


Holes and bearings can sometimes become blocked. Remove any debris using a pin or the like. The spray arms also have holes underneath.



To facilitate cleaning you can remove the spray arms. Remember to fit them firmly back into place afterwards.


### Top spray arm

- Pull out the top cutlery tray. Push up on the top spray arm while turning it anticlockwise to release it.




### Upper spray arm

- Pull out the upper basket.
- Unscrew the spray arm bearings anticlockwise to remove the spray arm from the upper basket.



### Lower spray arm

- Pull the lower spray arm straight up to release it.



## Clean the outside of the dishwasher

### Door and door seal

Open the door. Clean the sides of the door and the door seal regularly with a slightly damp cloth. Clean the door seal at the lower front edge of the dishwasher with a washing-up brush.

### Control panel

Keep the control panel clean. If necessary, wipe it with a dry or slightly damp cloth. Never use cleaning products – they may scratch the surface.

## CLn - Run the Self-clean program

### Dishwasher tub

The dishwasher tub is made of stainless steel and is kept clean through normal use (when used regularly).


If you have hard water, limescale deposits may build up in the dishwasher. If this happens, run Self-clean with two tablespoons of citric acid in the detergent compartment (with no dishes in the machine). Special dishwasher cleaners are also available on the market.

## Remove blockages

### Unblocking the drainage pump

If the dishwasher still contains water after the program has finished, something may be blocking the drainage pump, which results in the Water outlet fault error message.

1. Turn off the machine using ⓪ and remove the plug from the wall socket.
2. Remove the coarse filter and the fine filter.
3. Scoop out the water from the dishwasher tub.
4. In order to inspect the drainage pump, remove the yellow drainage pump stop on the right in the bottom drain. (Use a pair of pliers if necessary.)
5. Turn the pump wheel located behind the drainage pump stop by hand. Carefully remove any sharp items, such as glass.
6. Refit the drainage pump stop along with the fine and coarse filters.
7. Plug the machine in again.



### NOTE!

Do not forget to refit the drainage pump stop.


### Unblocking the inlet hose filter

If the water supply contains small particles, the outer filter on the inlet hose may become blocked, which results in the Water inlet fault error message.

1. Turn off the machine using ⓪ and remove the plug from the wall socket.
2. Turn off the water tap.
3. Unscrew the inlet hose.



4. Carefully remove the outer filter from the inlet hose and clean it.
5. Refit the filter and check that the gasket is correctly positioned.
6. Screw the inlet hose firmly into place.
7. Plug the machine into the wall socket and turn on the water tap. Allow the pressure to settle for a while and check that the connection is watertight.








# Troubleshooting

| Error messages |                        | Action  |
|----------------|------------------------|---|
| <b>F10</b>     | Overfilling water      | Clear the drainage pump. See the chapter <i>Care and cleaning</i> . If the problem persists, contact your nearest service centre.   |
| <b>F11</b>     | Water outlet fault     | See "Water remains in the dishwasher" under "Problem" in the table below. If the problem persists, contact your nearest service centre.   |
| <b>F12</b>     | Water inlet fault      | Check that the water tap is on. Check that the outer filter on the inlet hose is not blocked. See <i>Unblocking the inlet hose filter</i> in the chapter <i>Care and cleaning</i> . If the problem persists, contact your nearest service centre. |
| <b>F40</b>     | Inlet valve leakage    | Turn off the water tap and contact your nearest service centre.   |
| <b>F41</b>     | Heater fault 1         | Turn off the water tap. Remove the plug from the wall socket and contact your nearest service centre.   |
| <b>F45</b>     | Diverter fault         | Contact your nearest service centre.  |
| <b>F52</b>     | Water level fault      | Clean the coarse and fine filters. Check that the outer filter on the inlet hose is not blocked. If the problem persists, contact your nearest service centre.  |
| <b>F54</b>     | Overfilling water      | Turn off the water tap and contact your nearest service centre. To avoid water leakage outside the dishwasher, do not remove the plug from the wall socket until the water tap on the supply line has been turned off!                            |
| <b>F56</b>     | Circulation pump fault | Contact your nearest service centre.  |
| <b>F67</b>     | Water inlet fault      | Check that the water tap is on. Check that the outer filter on the inlet hose is not blocked. See <i>Unblocking the inlet hose filter</i> in the chapter <i>Care and cleaning</i> . If the problem persists, contact your nearest service centre. |
| <b>F68</b>     | BLDC drain pump fault  | Contact your nearest service centre.  |



Press any button to clear the error message.

| Problem  | Possible causes   | Action   |
|--|---|--|
| The control panel does not react when pressed. | You have pressed the control panel too soon after opening the door. | Wait a moment then try again.  |
|  | The door is closed.   | Open the door. The control panel only reacts to use when the door is open.           |
|  | Dirt on the control panel.  | Clean with a dry or slightly damp cloth.   |
| Cannot close door.                             | The baskets are not correctly positioned.                           | Check that the baskets are correctly positioned horizontally.                        |
|  |   | Check that the dishes are not blocking the baskets from sliding properly into place. |

| Problem                        | Possible causes   | Action  |
|--------------------------------|---|---|
|                                | The door lock does not click into place and lock.   | Check the door lock. If it does not click into place and lock, open the door.<br>Press and hold  Automatic door opening until the display starts counting down. Wait until the countdown ends (60 seconds). Close the door.<br>Check that the door lock clicks into place and locks. |
| The dishwasher does not start. |  has not been pressed. | Press  . The display starts counting down.   |
|                                | The door is not properly closed.  | Check.  |
|                                | You have opened the dishwasher to add more dishes while a program is in progress.                       | Close the door and wait. After a while, the dishwasher continues the program.   |
|                                | The door lock has not clicked into place and locked.  | Check the door lock. If it does not click into place and lock, open the door.<br>Press and hold  Automatic door opening until the display starts counting down. Wait until the countdown ends (60 seconds). Close the door.<br>Check that the door lock clicks into place and locks. |
|                                | Check whether the Delayed start option has been selected.   | Press and hold  for three seconds if you want to cancel the Delayed start option.  |
|                                | The plug is not plugged into the wall socket.   | Check.  |
|                                | A fuse/circuit breaker has been tripped.  | Check.  |
| The dishes are not clean.      | The spray arms do not rotate.   | Check that the dishes are not blocking the spray arms.  |
|                                | Spray arm holes or bearings blocked.  | Clean the spray arms. See the chapter <i>Care and cleaning</i> .  |
|                                | Unsuitable dishwashing program.   | Select a program with a high temperature to dissolve grease on very dirty dishes, such as Intensive 70°.  |
|                                | Incorrect detergent dosage.   | Dose according to water hardness. Far too much or far too little detergent results in poorer dishwashing results.   |
|                                | Old detergent. Detergent is a perishable product.   | Avoid large packages.   |


| <b>Problem</b>                      | <b>Possible causes</b>   | <b>Action</b>   |
|-------------------------------------|--|---|
|                                     | Dishes loaded incorrectly.   | Do not cover porcelain with large bowls or the like. Avoid placing very tall glasses in the corners of the baskets. See the chapter <i>Loading the dishwasher</i> . |
|                                     | Glasses and cups have toppled over during the program.   | Place dishes to sit steady.   |
|                                     | The filters are clogged.   | Clean the coarse and fine filters.  |
|                                     | The filters are not fitted correctly.  | Check that the filters are fitted correctly. See the chapter <i>Care and cleaning</i> .   |
|                                     | Drainage pump stop missing.  | Check that the yellow drainage pump stop on the right in the bottom drain is in place. See the chapter <i>Care and cleaning</i> .                                   |
| Spots on stainless steel or silver. | Some foodstuffs, such as mustard, mayonnaise, lemon, vinegar, salt and dressings, can cause spots on stainless steel if left for too long. | Rinse off these types of foodstuffs if not starting the dishwasher immediately. Consider using 1h 65° with the Speed wash option.                                   |
|                                     | All stainless steel can cause spots on silver if they come into contact during dishwashing. Aluminium can also cause spots on dishes.      | In order to avoid marks and tarnishing, separate dishes made from different metals, such as silver, stainless steel and aluminium.                                  |
| Spots or films on the dishes.       | Incorrect rinse aid dosage setting.  | See the chapter <i>Settings</i> .   |
|                                     | The setting TAB is activated and all-in-one detergent with insufficient drying effect is being used.                                       | Switch all-in-one detergents or deactivate the TAB setting and top up with salt and separate rinse aid. See Rinse aid in the chapter <i>Settings</i> .              |
|                                     | Salt compartment empty.  | Top up with salt. See the chapter <i>Before washing for the first time</i> .  |
|                                     | Incorrect water softener setting.  | See Water hardness in the chapter <i>Settings</i> .   |
|                                     | The water softener is leaking salt.  | Check that the salt compartment lid is properly tightened. Otherwise contact your nearest service centre.   |
|                                     | Too high temperature and/or too much detergent can cause etching on crystal. Unfortunately, this cannot be repaired, only prevented.       | Wash crystal at a low temperature and with a conservative amount of detergent. Contact the detergent manufacturer.  |

| <b>Problem</b>  | <b>Possible causes</b>  | <b>Action</b>  |
|---|---|--|
| The dishes have a sticky white/blue film.                         | Rinse aid dosage setting too high.                                      | Reduce the dosage. See the chapter <i>Settings</i> . If you have very soft water, you may want to dilute the rinse aid 50:50 with water.   |
| Spots left after washing.   | Lipstick and tea can be difficult to wash off.                          | Use a detergent with a bleaching agent.  |
| Detergent residue in the detergent compartment after dishwashing. | The detergent compartment was damp when adding detergent.               | The detergent compartment must be dry when adding detergent.   |
|   | The detergent compartment has been blocked.                             | Check that the dishes are not preventing the detergent compartment from opening.   |
| Rattling sound when dishwashing.                                  | The dishes are not correctly placed or the spray arms are not rotating. | Check that the dishes are placed securely. Spin the spray arms to make sure they can rotate.   |
| Water remains in the dishwasher.                                  | The filters are clogged.  | Clean the coarse and fine filters.   |
|   | The filters are not fitted correctly.                                   | Check that the filters are fitted correctly. See the chapter <i>Care and cleaning</i> .  |
|   | Debris in the drainage pump.  | Clean the drainage pump. See the chapter <i>Care and cleaning</i> .  |
|   | Drainage pump stop missing.   | Check that the yellow drainage pump stop on the right in the bottom drain is in place. See the chapter <i>Care and cleaning</i> .  |
|   | Kink in drainage hose.  | Check that the hose is free from kinks and sharp bends.  |
|   | Blocked drainage hose.  | Disconnect the drainage hose where it connects to the sink unit's water trap. Check that no debris has fastened and that the connection has an inner diameter of at least 14 mm. |
| Bad odour in dishwasher.  | Dirt around the seals and in corners.                                   | Clean with washing-up brush and low foaming cleaner.   |
|   | Low temperature programs have been selected for a prolonged period.     | Run a program with a high temperature once or twice a month. Or run a self-cleaning program. See Self-clean in the chapter <i>Using the dishwasher</i> .                         |

| <b>Problem</b>                     | <b>Possible causes</b>  | <b>Action</b>  |
|------------------------------------|---|--|
| Grease deposits in the dishwasher. | Low temperature programs have been selected for a prolonged period.   | Select a program with a high temperature to dissolve grease on very dirty dishes, such as Intensive 70°. Or run a self-cleaning program. See Self-clean in the chapter <i>Using the dishwasher</i> . |
| The dishes are not dry enough.     | The  Automatic door opening option is not activated. | Activate the  Automatic door opening option.  |
|                                    | The dishwasher is not fully loaded.   | Fully load the dishwasher.   |
|                                    | Rinse aid needs topping up or dosage is set too low.  | Top up with rinse aid or increase the rinse aid dosage setting.  |
|                                    | The setting TAB is activated and all-in-one detergent with insufficient drying effect is being used.                                  | Switch all-in-one detergents or deactivate the TAB setting and top up with salt and separate rinse aid. See Rinse aid in the chapter <i>Settings</i> .   |

# Installation

It is important that you read through and follow the instructions and directions below. Conduct installation and connection in accordance with the separate installation instructions.



\*Remove the plastic strips if the recess dimension is 596-598 mm.  
Exercise caution! The edges may be sharp. Wear protective gloves!

\*\*Cover door length.

Cover door with slide function fitted, which means the cover door slides upwards/outwards when the dishwasher is opened. *Nominal dimensions. Actual measurements may vary.*

## Safety instructions

- Connections to electricity, water and drainage must be performed by a qualified professional.
- Always follow applicable regulations for water, drainage and electricity.
- Take care during installation! Wear protective gloves! There must always be two people!
- Place a drip tray on the floor beneath the dishwasher to prevent damage from any water leaks.
- Before screwing the dishwasher into place, test the dishwasher by running the 1h 65° program with the Speed wash option. Check that the dishwasher fills with water and drains. Check also that none of the connections leak.



### WARNING!

Turn off the water supply when installing the dishwasher!

The plug must be disconnected or power to the socket turned off while the work is carried out!

## Setup

- The recess and connection dimensions are included in the separate installation instructions. Check that all dimensions are correct before starting the installation. Note that the height of the cover door can be adjusted to match other fittings.

- Make sure the area on which the dishwasher is to be installed is firm. Adjust the adjustable feet so that the dishwasher is level.
- If the dishwasher is built-in the surrounding furnishings must be resistant to any condensation from the dishwasher.
- Mount the protective film beneath the worktop and up around the edge. The function of the protective film is to protect the worktop from moisture. (The protective film is in the enclosed plastic bag.)
- Check that the machine is installed such that the door opens freely, otherwise door lock functionality may be disrupted.
- Note that the door springs may need adjusting after a cover door has been fitted. Adjust the left and right door springs equally until the door is evenly balanced.

## Drainage connection

This dishwasher is suitable for installing in a raised recess (to attain an ergonomic working height). This means that the dishwasher can be placed so that the drainage hose runs to a lower level than the bottom of the dishwasher, such as by routing it directly to a floor drain. The dishwasher is fitted with an integrated anti-siphon device to prevent the machine from being emptied of water during the wash cycle.

The drainage hose can also be connected to a connection nipple on the sink unit's water trap. The connection nipple must have an internal diameter of at least 14 mm.

The drainage hose may be extended by a maximum of 3 m (the total length of the drainage hose must not exceed 4.5 m). Any joins and connecting pipes must have an internal diameter of at least 14 mm. However, the drainage hose should ideally be replaced with a new hose without joins.

No part of the drainage hose may be more than 950 mm above the bottom of the dishwasher.

Attach the drainage hose with a hose clamp. Ensure that the drainage hose has no kinks.

## Connection to water supply

Use only the inlet hose supplied with the dishwasher. Do not re-use old or other spare hoses.

The supply pipe must be fitted with a water tap (stopcock). The water tap must be easily accessible, so that the water can be shut off if the dishwasher has to be moved.

Once the installation is complete, turn on the water tap and allow the pressure to settle for a while. Check that all connections are watertight.

## Connection to cold water supply

Connect the dishwasher to the cold water supply if the building is heated using oil, electricity or gas.

## Connection to hot water supply

Connect the dishwasher to the hot water supply (max. 70 °C) if the building is heated using an energy-efficient means such as district heating, solar power or geothermal power. Choosing a hot water connection reduces the dishwasher's energy consumption.

### NOTE!

Do not exceed the permitted water supply temperature. Certain materials used in some cookware cannot withstand high heat. See *Fragile dishes* in the chapter *Loading the dishwasher*.



## **Electrical connection**

Information about the electrical connection can be found on the serial number plate. This specification must match the electricity supply.

The dishwasher must be connected to an earthed socket.


The electric wall socket must be placed outside of the installation area to be easily accessible after installing the dishwasher. Do not use an extension cord!

# Service

Read the chapter *Troubleshooting* before contacting the service centre. If you have encountered a problem that you cannot resolve, please contact your nearest service centre for professional help, see [www.etna.nl](http://www.etna.nl). Our website also has information about spare part availability and what you can repair yourself.

When making contact, provide the details on the serial number plate. Include the article number (1) and the serial number (2).

Please note that non-professional repairs may risk user safety and affect the warranty.



# Technical data and energy labelling

## Technical data

|                                    |                             |
|------------------------------------|-----------------------------|
| Height:                            | 856-906 mm                  |
| Width:                             | 598 mm                      |
| Depth:                             | 555 mm                      |
| Weight:                            | 35 kg <sup>1)</sup>         |
| Number of standard place settings: | 16 <sup>2)</sup>            |
| Water pressure:                    | 0.03-1.0 MPa                |
| Electrical connection:             | See the serial number plate |
| Rated power:                       | See the serial number plate |

1) *Weight can vary due to different specifications.*

2) *In accordance with the EN 60436 standard.*

## Information for consumers

Information about your product can be found at [www.etna.nl](http://www.etna.nl), where you will also find a link to the European Product Database for Energy Labelling, EPREL. Or else visit <https://eprel.ec.europa.eu> directly. Follow the instructions to search by model name.


See the information on the serial number plate. Make a note of the model name (3).

This appliance contains a light source/light sources of energy efficiency class D. Light sources are available as spare parts and can be replaced by your nearest service centre or a qualified professional.

## Information for test institute

Information about this product can be found in the European Product Database for Energy Labelling, EPREL, and can also be ordered by e-mail [dishwashers@appliance-development.com](mailto:dishwashers@appliance-development.com).

The request should include the details on the serial number plate. Include the article number (1), the serial number (2) and the model name (3).





[www.etna.nl](http://www.etna.nl)



879830-a1



*We reserve the right to make changes.*