

Centre distance in mm

FL = front left; **RL** = rear left; **RR** = rear right; **FR** = front right; **CF** = centre front;
CR = centre rear; **CL** = centre left; **CR** = centre right

FL-FR	RL-FL	RR-FR	RL-RR	FL-WOK	RL-WOK
240	245	245	240	290	270

Location gas connection: -