

D

Montageanweisung

- bitte aufbewahren -

GB

Installations Instructions

- please don't throw it away -

F

Instructions de montage

- à conserver -

NL

Montage-aanwijzing

- bewaren a. u. b. -

I

Istruzioni per il montaggio

- Attenzione: conservare -

E

Instrucciones de montaje

- pore favor guardarlas -

P

Instruções de montagem

- e favor guardar -

DK

Montageanvisning

- bedes opbevaret -

S

Monteringsanvisning

- bewara för senare bruk -

N

Monteringsanvisning

- ta godt vare på denne -

FIN

Asennusohje

- Säilytä huolella -

falls vorhanden


only supplied with certain models

si la cas

niet bij alle apparaten aanwezig

se esistente

✿



adjustable RAIL SYSTEM

with cover screws

RE220A/W

Printed in Italy 10/11

5019 102 00868








Diagram illustrating the assembly of the door frame using 4 screws (3,9 x 9,5). The diagram shows the door frame being attached to the main unit. Callouts show the screws being used and the specific locations on the frame where they are installed.

PRÜFEN
CHECK
CONTROLEREN
CONTROLLARE

min 1 mm

Readjust if necessary
Resserer au besoin
Indien noodzakelijk nastellen
Se necessario, regolare

The diagram illustrates the process of adjusting the refrigerator door hinge. The main image shows a refrigerator with its door open. Three circular callouts provide detailed steps: 1. Loosening the hinge screw with a screwdriver. 2. Using a level to check the door's alignment. 3. Tightening the hinge screw and adjusting the door's position.

10

2 x 3,9 x 9,5

3 x 4 x 15

20 mm

Nur für geteilte Möbeltür
Only for wooden door realised in two pieces
Uniquement pour portes a plusieurs éléments
Allen voor dubbele meubeldeur
Solo per antine in legno realizzate in due pezzi