



DOOR PARTS








CONTROLLER PARTS




OVEN CAVITY PARTS



* Check the Rating Model No.

Origin	New
 4B70572B  3052W3M018A 	 3052W3A015A 
Origin → Early New → Late	
Original parts only may be used in early production sets. New parts may be used in late production sets only. Stock original and new parts.	



* Check the Rating Model No.



* Check the Rating Model No.




LATCH BOARD PARTS



INTERIOR PARTS

* Check the Rating Model No.



* Check the Rating Model No.

For model
MAG525WIT / P01
MAG525ZWART / P01
MAG525ZWART / P02

56851D
 56851C

* Check the Rating Model No.

For model
MAG525ZWART / P03

56851C

WSZ002

BASE PLATE PARTS

