

Error	Problem	Cause or remedy	Process (service technician)
F0	F0 on display.	<ul style="list-style-type: none"> • User interface in malfunction. • Repair is carried out by authorized Servis. 	<ul style="list-style-type: none"> • Control module.
F1	F1 on display.	<ul style="list-style-type: none"> • Touch sensor error on the control module. # One of the sensors/keys is activated too long (dirt, covered) • Repair is carried out by authorized Servis. 	<ul style="list-style-type: none"> • Control module. • See service manual (depends on model) [blink]4-037-1841[/bl
F2	F2 on display.	<ul style="list-style-type: none"> • Too high temperature on the control module. • Excessive cooking zone temperature or overheating of the in # Wait for appliance too cool down. # Check the installation of the appliance or remove the hot pot 	<ul style="list-style-type: none"> • Cooling fan. • See service manual (depends on model) [blink]4-037-1841[/bl
F3	F3 on display.	# Inappropriate pot.	<ul style="list-style-type: none"> • Generator/Module induction. • See service manual (depends on model) [blink]4-037-1841[/bl
F4	F4 on display.	<ul style="list-style-type: none"> • The appliance is not configured, it has an incorrect configurat • Repair is carried out by authorized Servis. 	<ul style="list-style-type: none"> • Configure the existing control module. • See service manual (depends on model) [blink]4-037-1841[/bl
F5	F5 on display.	<ul style="list-style-type: none"> • Communication error between electronic modules. # Check that the appliance is connected to the mains in accor 	<ul style="list-style-type: none"> • See service manual (depends on model) [blink]4-037-1841[/bl • Connection cable. • Generator/Module induction. • Control module.
F6	F6 on display.	# Check that the appliance is connected to the mains in accor	<ul style="list-style-type: none"> • Generator/Module induction.
F8	F8 on display.	<ul style="list-style-type: none"> • Cooling fan in malfunction. • Repair is carried out by authorized Servis. 	<ul style="list-style-type: none"> • Cooling fan. • Generator/Module induction. • See service manual (depends on model) [blink]4-037-1841[/bl
F9	F9 on display.	<ul style="list-style-type: none"> • Temperature sensor in malfunction. • Repair is carried out by authorized Servis. 	<ul style="list-style-type: none"> • See service manual (depends on model) [blink]4-037-1841[/bl
FA	FA on display.	<ul style="list-style-type: none"> • Internal error of the induction module. • Repair is carried out by authorized Servis. 	<ul style="list-style-type: none"> • Generator/Module induction.
FH	FH on display.	<ul style="list-style-type: none"> • Excessive cooking zone temperature or overheating of the in # Empty pot is on cooktop. # Wait for appliance too cool down. 	<ul style="list-style-type: none"> • See service manual (depends on model) [blink]4-037-1841[/bl