

Fout	Probleem	Oorzaak of oplossing	Proces (service monteur)
Flashing LED 1	Communication failure between power and logic module.	<ul style="list-style-type: none"> The appliance doesn't cool down the room. # Check the connection of the appliance to the mains in accordance with the Operating Instructions and the electrical supply in the outlet. Repair is carried out by authorized Servis. 	<ul style="list-style-type: none"> Connecting cable and connector. TC module/user interface. Power board.
Flashing LED 2	The refrigerator is too cold.	<ul style="list-style-type: none"> Failure of the temperature sensor. The temperature sensor in the refrigerator is blocked with fresh food. Maximum temperature setting. # We recommend a medium temperature setting. 	<ul style="list-style-type: none"> Connecting cable and connector. Temperature sensor. Flap. Fan.
Flashing LED 3	The freezer compartment does not freeze.	<ul style="list-style-type: none"> Unsuitable room - ambient temperature too low. # To consider to the chapter Selecting the room. Repair is carried out by authorized Servis. 	<ul style="list-style-type: none"> Connecting cable and connector. Temperature sensor. Compressor. The operation of cooling system elements (leakage).
Flashing LED 5	Ice at the rear part of freezer compartment evaporator.	<ul style="list-style-type: none"> The appliance continues to function, the basic function is guaranteed. Failure of temperature sensor on evaporator in freezer compartment. 	<ul style="list-style-type: none"> Connecting cable and connector. Defrosting temperature sensor. Heater.
Flashing LED 7	Appliance reports that the door is not closed.	<ul style="list-style-type: none"> Door is opened. Door switch failure. 	<ul style="list-style-type: none"> Connecting cable and connector. Door switch.