Error code	Fault	Fault description	Process (client)	Process (service technician)
	Filter cover opens by itself	Filter cover opens by itself. Filter cover opens itself like it wouldn't be closed in inner frame.	When customer opens filter cover, they can accidentally remove filter gasket. They can put back on wrong position. Cover can't close or does very hard. For correct placement check document [blnk] 4-027-1604[/blnk]	check correct placement of filter gasket according document [blnk]4-027-1604[/blnk]