| Error | Problem | Cause or remedy | Process (service technician) |
|-------|-----------------|--|---|
| F10 | F10 on display. | Water Inlet fault. Too much water inside the machine. Repair is carried out by authorized Servis. | Drain pump. Outlet hose. Flowmeter. Electro valve. Wiring harness. Aqua stop sensor. |
| F11 | F11 on display. | Water outlet fault. Drain pump doesn't drain water. Hydraulic sump clogged Drain pump clogged Clogged drain hose or siphon Filter # Run a program and if error repeats call authorized Service. | Drain pump calibration - Service information [blnk]4-127-161 Drain pump. Wiring harness. |
| F12 | F12 on display. | Water Inlet fault. Flowmeter didn't detect enough pulses. Pr # Check water tap. # Run a program and if error repeats call authorized Service. | Plowmeter. Electro valve. Control unit. |
| F40 | F40 on display. | Leakage on the inlet valve. Flowmeter detected leakage on i # Close water tap. Repair is carried out by authorized Servis. | Electro valve. Pressure sensor. Hoses. |
| F41 | F41 on display. | Heating fault. In case of heater fault the machine continues Repair is carried out by authorized Servis. | Heater. Temperature sensor. Pressure sensor. Circulation pump. Control unit. |
| F42 | F42 on display. | Temperature sensor fault (Detected temperature out of range Repair is carried out by authorized Servis. | Temperature sensor. Wiring harness. Control unit. |
| F43 | F43 on display. | Pressure sensor fault. Repair is carried out by authorized Servis. | Pressure sensor. Control unit. Wiring harness. |
| F44 | F44 on display. | Turbidity sensor fault. Repair is carried out by authorized Servis. | Turbidity sensor. Wiring harness. Control unit. |
| F45 | F45 on display. | Diverter valve fault. Repair is carried out by authorized Servis. | Diverter valve. Wiring harness. |
| F52 | F52 on display. | Water level 1 fault. Repair is carried out by authorized Servis. | Pressure sensor. Electro valve. Flowmeter. Check air break. Check drain hose. |
| F53 | F53 on display. | Water level 2 fault. # Clean the filter. # Clean drain hose. # Clean siphon. | Drain pump. Flowmeter. Electro valve. Clean filter. Check drain hose. |
| F54 | F54 on display. | Float switch fault. Float switch activated. Repair is carried out by authorized Servis. | [blnk]4-123-1708[/blnk]. |
| F56 | F56 on display. | Circulation pump fault. Repair is carried out by authorized Servis. | Circulation pump. Control unit. Wiring harness. |
| | CLN on display. | # Appliance must be cleaned. Clean spray arms and filters an | |