

1

6x
(38 mm)

2

4x
(25 mm)
Torx T20

3

2x

4

5

2x

6

7

8

2x
(15 mm)
Torx T20

PH 2

24 mm

Ø 3 mm

Torx T20

Scissors

*

EN Only certain models.
If the following parts are not supplied with your dishwasher, they are not intended for your specific model.

AR

في موديلات معينة.

BG

Само определени модели.

CS

Pouze některé modely.

CN

仅限部分型号。

DA

Kun visse modeller.

DE

Nur bei bestimmten Modellen.

ES

Sólo se aplica a determinados modelos.

ET

Ainult teatud mudelitel.

FA

فقط بعضی از مدل ها.

FI

Vain tietyt mallit.

FR

Uniquement pour certains modèles.

HR

Samo na nekim modelima.

HU

Csak bizonyos modellek esetében.

IT

Solo per alcuni modelli.

KK

Тек белгілі бір модельдер.

LT

Tik tam tikri modeliai.

LV

Vienīgi noteiktiem modeļiem.

NL

Alleen bepaalde modellen.

NO

Bare enkelte modeller.

PL

Dotyczy tylko wybranych modeli.

RO

Numai la anumite modele.

RU

Только в некоторых моделях.

SK

Iba niektoré modely.

SL

Samo nekateri modeli.

SQ

Vetëm disa modele të caktuara.

SR

Samo neki modeli.

SV

Endast vissa modeller.

UK

Тільки в деяких моделях.

1

L

XXL

?

SAFETY

Size: L/XXL

ART. NO.

SERIAL NO.

820-893

860-908

L

XXL

min. 555

600

125

55

min. 50x100

!

!

!

!

2

REMOVE

!

3

4

!

4

2x

24 mm

1x

Max 0.6 Nm

Torx T20

min. 5 mm

min. 3 mm

5

L

640-720

XXL

700-800

XXL

720-800 FANDRY

596

L

3-10 kg

XXL

3-9 kg

!

6

7

96

8

2x
(15 mm)
Torx T20

Ø 3 mm

12 mm

We reserve the right to make changes.

