Centre distance in mm

FL = front left; **RL** = rear left; **RR** = rear right; **FR** = front right; **CF** = centre front; **CR** = centre rear; **CL** = centre left; **CR** = centre right

 FL-FR
 FL-CL
 CL-CR
 CR-FR
 FL-WOK
 RL-WOK

 810
 290
 230
 290

Location gas connection: -