


# DOOR PARTS



24781T

26549T

23572A

249402


WTP015

249401

24510L




24970A

250201




# OVEN CAVITY PARTS

\* Check the Rating Model No.



Origin	New
 <p>4B70572B</p> <p>WSZ092</p>  <p>3052W3M018A</p> <p>33052M</p>	 <p>3052W3A015A</p> <p>33052A</p>
Origin → Early	New → Late
<p>Original parts only may be used in early production sets.                      New parts may be used in late production sets only.                      Stock original and new parts.</p>	

\* Check the Rating Model No.




\* Check the Rating Model No.

# LATCH BOARD PARTS



# INTERIOR PARTS

\* Check the Rating Model No.



\* Check the Rating Model No.

**56851D**

**56851C**

**For model**  
**MAG525WIT / P01**  
**MAG525ZWART / P01**  
**MAG525ZWART / P02**


\* Check the Rating Model No.

**56851C**

**For model**  
**MAG525ZWART / P03**

WSZ002

# BASE PLATE PARTS



\* Check the Rating Model No.

56170D

\* Check the Rating Model No.

63302A

63303A

65006B

WTT021

WSZ002