

Spark electrodes

Burner switches (push)  
Mounted on gas taps

Ignitor  
220-240V/50-60Hz

Gas tap 4

Thermocouple 4

Gas tap 3

Thermocouple 3

Gas tap 2

Thermocouple 2

Gas tap 1

Thermocouple 1

L  
N  
Earth

