

Error	Problem	Cause or remedy	Process (service technician)
F10	F10 on display.	<ul style="list-style-type: none"> • Overfilling. Too much water inside the machine. # Clean the filter. • Filter is not correctly assembled. # Clean drain pump. # Clean siphon. # Clean drain hose. • Kinked drain hose. # Run a program and if error repeats call authorized Service. 	<ul style="list-style-type: none"> • Drain pump. • Outlet hose. • Flowmeter. • Electro valve. • Wiring harness / connector. • Pressure sensor.
F11	F11 on display.	<ul style="list-style-type: none"> • Water outlet fault. Drain pump doesn't drain water. # Clean the filter # Filter is not correctly assembled • Drain pump clogged • Hydraulic sump clogged • Clogged drain hose or siphon # Clean drain pump # Clean drain hose # Clean siphon • Kinked drain hose # Run a program and if error repeats call authorized Service. 	<ul style="list-style-type: none"> • Drain pump calibration. Reset 02. • Drain pump. • Wiring harness. • Pressure sensor.
F12	F12 on display.	<ul style="list-style-type: none"> • Water Inlet fault. Flowmeter didn't detect enough pulses. Pr # Check water tap. # Check that the outer filter on the inlet hose is not blocked # Run a program and if error repeats call authorized Service. 	<ul style="list-style-type: none"> • Flowmeter. Time filling • Electro valve. • Aqua stop inlet hose • Wiring harness • Control unit.
F40	F40 on display.	<ul style="list-style-type: none"> • Leakage on the inlet valve. Flowmeter detected leakage on i # Close water tap. • Repair is carried out by authorized Servis. 	<ul style="list-style-type: none"> • Electro valve. • Pressure sensor. • Hoses.
F41	F41 on display.	<ul style="list-style-type: none"> • Heating fault. In case of heater fault the machine continues • Repair is carried out by authorized Servis. 	<ul style="list-style-type: none"> • Heater. • Temperature sensor. • Pressure sensor. • Circulation pump. • Control unit.
F42	F42 on display.	<ul style="list-style-type: none"> • Temperature sensor fault (Detected temperature out of range • Repair is carried out by authorized Servis. 	<ul style="list-style-type: none"> • Temperature sensor. • Wiring harness. • Control unit.
F43	F43 on display.	<ul style="list-style-type: none"> • Pressure sensor fault. • Repair is carried out by authorized Servis. 	<ul style="list-style-type: none"> • Pressure sensor. • Control unit. • Wiring harness.
F44	F44 on display.	<ul style="list-style-type: none"> • Turbidity sensor fault. • Repair is carried out by authorized Servis. 	<ul style="list-style-type: none"> • Turbidity sensor. • Wiring harness. • Control unit.
F45	F45 on display.	<ul style="list-style-type: none"> • Diverter valve fault. • Repair is carried out by authorized Servis. 	<ul style="list-style-type: none"> • Diverter valve. • Wiring harness.
F52	F52 on display.	<ul style="list-style-type: none"> • Clogged filters fault. # Clean the filter. • Filter is not correctly assembled. # Clean siphon. # Clean drain hose • Kinked drain hose. # Clean drain pump. • Repair is carried out by authorized Servis. 	<ul style="list-style-type: none"> • Pressure sensor.[bInk]4-123-2004[/bInk] • Electro valve. • Flowmeter. • Check air break. • Check drain hose.
F53	F53 on display.	<ul style="list-style-type: none"> • Water level 2 fault. # Clean the filter. # Clean drain hose. # Clean siphon. 	<ul style="list-style-type: none"> • Drain pump. • Flowmeter. • Electro valve. • Clean filter. • Check drain hose.

Error	Problem	Cause or remedy	Process (service technician)
F54	F54 on display.	<ul style="list-style-type: none"> • Float switch fault. Leakage. Float switch activated. # Clogged drain hose or siphon. # Check that the inlet and outlet hoses are not leaking. # Check that the drain pump is not clogged. # Check that the colored stop of the drain pump (yellow plug) i # If the pump is not clogged and the hose is not leaking, there # Restart the program. If the error occurs again, close the wat • Repair is carried out by authorized Servis 	<ul style="list-style-type: none"> • Find leakage. • Floater microswitch.
F56	F56 on display.	<ul style="list-style-type: none"> • Circulation pump fault. # Clean the filter. • Filter is not correctly assembled # Clean siphon # Clean drain hose • Kinked drain hose # Clean drain pump # Run a program and if error repeats call authorized Service. • Repair is carried out by authorized Servis. 	<ul style="list-style-type: none"> • Wiring harness. • Control unit. • Circulation pump.
F61	F61 on display.	<ul style="list-style-type: none"> • Water tank fault. • Repair is carried out by authorized Servis. 	<ul style="list-style-type: none"> •Water tank valve. •Pressure sensor. •Clogged water tank or hose.
F67	F67 on display.	<ul style="list-style-type: none"> • Water Inlet fault. Program stops. # Check water tap. # Check that the outer filter on the inlet hose is not blocked # Run a program and if error repeats call authorized Service. 	<ul style="list-style-type: none"> •Pressure sensor. •Electro valve. •Aqua stop inlet hose. •Wiring harness. •Control unit.