

Error	Problem	Cause or remedy	Process (service technician)
F10	F10 on display.	<ul style="list-style-type: none"> <li>• Overfilling.  Too much water inside the machine.</li> <li># Clean the filter.</li> <li>• Filter is not correctly assembled.</li> <li># Clean drain pump.</li> <li># Clean siphon.</li> <li># Clean drain hose.</li> <li>• Kinked drain hose.</li> <li># Run a program and if error repeats call authorized Service.</li> </ul>	<ul style="list-style-type: none"> <li>• Drain pump.</li> <li>• Outlet hose.</li> <li>• Flowmeter.</li> <li>• Electro valve.</li> <li>• Wiring harness / connector.</li> <li>• Pressure sensor.</li> </ul>
F11	F11 on display.	<ul style="list-style-type: none"> <li>• Water outlet fault.  Drain pump doesn't drain water.</li> <li># Clean the filter</li> <li># Filter is not correctly assembled</li> <li>• Drain pump clogged</li> <li>• Hydraulic sump clogged</li> <li>• Clogged drain hose or siphon</li> <li># Clean drain pump</li> <li># Clean drain hose</li> <li># Clean siphon</li> <li>• Kinked drain hose</li> <li># Run a program and if error repeats call authorized Service.</li> </ul>	<ul style="list-style-type: none"> <li>• Drain pump calibration  Reset 02  Service information [blnk]4</li> <li>• Drain pump.</li> <li>• Wiring harness.</li> <li>• Pressure sensor.</li> </ul>
F12	F12 on display.	<ul style="list-style-type: none"> <li>• Water Inlet fault.  Flowmeter didn't detect enough pulses.  Pr</li> <li># Check water tap.</li> <li># Check that the outer filter on the inlet hose is not blocked</li> <li># Run a program and if error repeats call authorized Service.</li> </ul>	<ul style="list-style-type: none"> <li>•Flowmeter. Time filling</li> <li>•Electro valve.</li> <li>•Aqua stop inlet hose</li> <li>•Wiring harness</li> <li>•Control unit.</li> </ul>
F40	F40 on display.	<ul style="list-style-type: none"> <li>• Leakage on the inlet valve.  Flowmeter detected leakage on i</li> <li># Close water tap.</li> <li>• Repair is carried out by authorized Servis.</li> </ul>	<ul style="list-style-type: none"> <li>•Electro valve.</li> <li>•Pressure sensor.</li> <li>• Hoses.</li> </ul>
F41	F41 on display.	<ul style="list-style-type: none"> <li>• Heating fault.  In case of heater fault the machine continues</li> <li>• Repair is carried out by authorized Servis.</li> </ul>	<ul style="list-style-type: none"> <li>•Heater.</li> <li>•Temperature sensor.</li> <li>•Pressure sensor.</li> <li>• Circulation pump.</li> <li>•Control unit.</li> </ul>
F42	F42 on display.	<ul style="list-style-type: none"> <li>• Temperature sensor fault (Detected temperature out of range</li> <li>• Repair is carried out by authorized Servis.</li> </ul>	<ul style="list-style-type: none"> <li>•Temperature sensor.</li> <li>•Wiring harness.</li> <li>•Control unit.</li> </ul>
F43	F43 on display.	<ul style="list-style-type: none"> <li>• Pressure sensor fault.</li> <li>• Repair is carried out by authorized Servis.</li> </ul>	<ul style="list-style-type: none"> <li>•Pressure sensor.</li> <li>•Control unit.</li> <li>•Wiring harness.</li> </ul>
F44	F44 on display.	<ul style="list-style-type: none"> <li>• Turbidity sensor fault.</li> <li>• Repair is carried out by authorized Servis.</li> </ul>	<ul style="list-style-type: none"> <li>•Turbidity sensor.</li> <li>•Wiring harness.</li> <li>•Control unit.</li> </ul>
F45	F45 on display.	<ul style="list-style-type: none"> <li>• Diverter valve fault.</li> <li>• Repair is carried out by authorized Servis.</li> </ul>	<ul style="list-style-type: none"> <li>•Diverter valve.</li> <li>•Wiring harness.</li> </ul>
F52	F52 on display.	<ul style="list-style-type: none"> <li>• Clogged filters fault.</li> <li># Clean the filter.</li> <li>• Filter is not correctly assembled.</li> <li># Clean siphon.</li> <li># Clean drain hose</li> <li>• Kinked drain hose.</li> <li># Clean drain pump.</li> <li>• Repair is carried out by authorized Servis.</li> </ul>	<ul style="list-style-type: none"> <li>•Pressure sensor.[blnk]4-123-2004/[blnk]</li> <li>•Electro valve.</li> <li>•Flowmeter.</li> <li>• Check air break.</li> <li>• Check drain hose.</li> </ul>
F61	F61 on display.	<ul style="list-style-type: none"> <li>• Water tank fault.</li> <li>• Repair is carried out by authorized Servis.</li> </ul>	<ul style="list-style-type: none"> <li>•Water tank valve.</li> <li>•Pressure sensor.</li> <li>•Clogged water tank or hose.</li> </ul>

Error	Problem	Cause or remedy	Process (service technician)
F53	F53 on display.	<ul style="list-style-type: none"> <li>• Water level 2 fault.</li> <li># Clean the filter.</li> <li># Clean drain hose.</li> <li># Clean siphon.</li> </ul>	<ul style="list-style-type: none"> <li>• Drain pump.</li> <li>• Flowmeter.</li> <li>• Electro valve.</li> <li>• Clean filter.</li> <li>• Check drain hose.</li> </ul>
F54	F54 on display.	<ul style="list-style-type: none"> <li>• Float switch fault.  Leakage.  Float switch activated.</li> <li># Clogged drain hose or siphon.</li> <li># Check that the inlet and outlet hoses are not leaking.</li> <li># Check that the drain pump is not clogged.</li> <li># Check that the colored stop of the drain pump (yellow plug) i</li> <li># If the pump is not clogged and the hose is not leaking, there</li> <li># Restart the program.  If the error occurs again, close the wat</li> <li>• Repair is carried out by authorized Servis</li> </ul>	<ul style="list-style-type: none"> <li>• Find leakage. [blink]4-123-1708[/blink].</li> <li>• Floater microswitch</li> </ul>
F56	F56 on display.	<ul style="list-style-type: none"> <li>• Circulation pump fault.</li> <li># Clean the filter.</li> <li>• Filter is not correctly assembled</li> <li># Clean siphon</li> <li># Clean drain hose</li> <li>• Kinked drain hose</li> <li># Clean drain pump</li> <li># Run a program and if error repeats call authorized Service.</li> <li>• Repair is carried out by authorized Servis.</li> </ul>	<ul style="list-style-type: none"> <li>• Wiring harness.</li> <li>• Control unit.</li> <li>• Circulation pump.</li> </ul>
	CLN on display.	# Appliance must be cleaned.  Clean spray arms and filters an	
F67	F67 on display.	<ul style="list-style-type: none"> <li>• Water Inlet fault.  Program stops.</li> <li># Check water tap.</li> <li># Check that the outer filter on the inlet hose is not blocked</li> <li># Run a program and if error repeats call authorized Service.</li> </ul>	<ul style="list-style-type: none"> <li>• Pressure sensor.</li> <li>• Electro valve.</li> <li>• Aqua stop inlet hose.</li> <li>• Wiring harness.</li> <li>• Control unit.</li> </ul>