

| Error | Problem | Cause or remedy | Process (service technician) |
|-------|-----------------|---|--|
| F10 | F10 on display. | <ul style="list-style-type: none"> • Overfilling. Too much water inside the machine. # Clean the filter. • Filter is not correctly assembled. # Clean drain pump. # Clean siphon. # Clean drain hose. • Kinked drain hose. # Run a program and if error repeats call authorized Service. | <ul style="list-style-type: none"> • Drain pump. • Outlet hose. • Flowmeter. • Electro valve. • Wiring harness / connector. • Pressure sensor. |
| F11 | F11 on display. | <ul style="list-style-type: none"> • Water outlet fault. Drain pump doesn't drain water. # Clean the filter # Filter is not correctly assembled • Drain pump clogged • Hydraulic sump clogged • Clogged drain hose or siphon # Clean drain pump # Clean drain hose # Clean siphon • Kinked drain hose # Run a program and if error repeats call authorized Service. | <ul style="list-style-type: none"> • Drain pump calibration. Reset 02. • Drain pump. • Wiring harness. • Pressure sensor. |
| F12 | F12 on display. | <ul style="list-style-type: none"> • Water Inlet fault. Flowmeter didn't detect enough pulses. Pr # Check water tap. # Check that the outer filter on the inlet hose is not blocked # Run a program and if error repeats call authorized Service. | <ul style="list-style-type: none"> • Flowmeter. Time filling • Electro valve. • Aqua stop inlet hose • Wiring harness • Control unit. |
| F40 | F40 on display. | <ul style="list-style-type: none"> • Leakage on the inlet valve. Flowmeter detected leakage on i # Close water tap. • Repair is carried out by authorized Servis. | <ul style="list-style-type: none"> • Electro valve. • Pressure sensor. • Hoses. |
| F41 | F41 on display. | <ul style="list-style-type: none"> • Heating fault. In case of heater fault the machine continues • Repair is carried out by authorized Servis. | <ul style="list-style-type: none"> • Heater. • Temperature sensor. • Pressure sensor. • Circulation pump. • Control unit. |
| F42 | F42 on display. | <ul style="list-style-type: none"> • Temperature sensor fault (Detected temperature out of range • Repair is carried out by authorized Servis. | <ul style="list-style-type: none"> • Temperature sensor. • Wiring harness. • Control unit. |
| F43 | F43 on display. | <ul style="list-style-type: none"> • Pressure sensor fault. • Repair is carried out by authorized Servis. | <ul style="list-style-type: none"> • Pressure sensor. • Control unit. • Wiring harness. |
| F44 | F44 on display. | <ul style="list-style-type: none"> • Turbidity sensor fault. • Repair is carried out by authorized Servis. | <ul style="list-style-type: none"> • Turbidity sensor. • Wiring harness. • Control unit. |
| F45 | F45 on display. | <ul style="list-style-type: none"> • Diverter valve fault. • Repair is carried out by authorized Servis. | <ul style="list-style-type: none"> • Diverter valve. • Wiring harness. |
| F52 | F52 on display. | <ul style="list-style-type: none"> • Clogged filters fault. # Clean the filter. • Filter is not correctly assembled. # Clean siphon. # Clean drain hose • Kinked drain hose. # Clean drain pump. • Repair is carried out by authorized Servis. | <ul style="list-style-type: none"> • Pressure sensor.[bInk]4-123-2004[/bInk] • Electro valve. • Flowmeter. • Check air break. • Check drain hose. |
| F53 | F53 on display. | <ul style="list-style-type: none"> • Water level 2 fault. # Clean the filter. # Clean drain hose. # Clean siphon. | <ul style="list-style-type: none"> • Drain pump. • Flowmeter. • Electro valve. • Clean filter. • Check drain hose. |

| Error | Problem | Cause or remedy | Process (service technician) |
|-------|-----------------|--|--|
| F54 | F54 on display. | <ul style="list-style-type: none"> • Float switch fault. Leakage. Float switch activated. # Clogged drain hose or siphon. # Check that the inlet and outlet hoses are not leaking. # Check that the drain pump is not clogged. # Check that the colored stop of the drain pump (yellow plug) i # If the pump is not clogged and the hose is not leaking, there # Restart the program. If the error occurs again, close the wat • Repair is carried out by authorized Servis | <ul style="list-style-type: none"> • Find leakage. • Floater microswitch. |
| F56 | F56 on display. | <ul style="list-style-type: none"> • Circulation pump fault. # Clean the filter. • Filter is not correctly assembled # Clean siphon # Clean drain hose • Kinked drain hose # Clean drain pump # Run a program and if error repeats call authorized Service. • Repair is carried out by authorized Servis. | <ul style="list-style-type: none"> • Wiring harness. • Control unit. • Circulation pump. |
| F61 | F61 on display. | <ul style="list-style-type: none"> • Water tank fault. • Repair is carried out by authorized Servis. | <ul style="list-style-type: none"> •Water tank valve. •Pressure sensor. •Clogged water tank or hose. |
| F67 | F67 on display. | <ul style="list-style-type: none"> • Water Inlet fault. Program stops. # Check water tap. # Check that the outer filter on the inlet hose is not blocked # Run a program and if error repeats call authorized Service. | <ul style="list-style-type: none"> •Pressure sensor. •Electro valve. •Aqua stop inlet hose. •Wiring harness. •Control unit. |