

Error	Problem	Cause or remedy	Process (service technician)
E0	E0 on the refrigerator display.	<ul style="list-style-type: none"> <li>The appliance continues to function, the basic function is guaranteed.</li> <li>Communication failure between power and logic module.</li> <li>Repair is carried out by authorized Service.</li> </ul>	<ul style="list-style-type: none"> <li>Connecting cable and connector.</li> <li>Logic board.</li> <li>Power board.</li> </ul>
E0	E0 on display Durafresh.	<ul style="list-style-type: none"> <li>The appliance continues to function, the basic function is guaranteed.</li> <li>Communication failure between power and Durafresh module.</li> <li>Repair is carried out by authorized Service.</li> </ul>	<ul style="list-style-type: none"> <li>Connecting cable and connector.</li> <li>Durafresh module.</li> <li>Power board.</li> </ul>
E1	E1 on the refrigerator display.	<ul style="list-style-type: none"> <li>The appliance continues to function, the basic function is guaranteed.</li> <li>Failure of temperature sensor in refrigerator compartment.</li> <li>Repair is carried out by authorized Service.</li> </ul>	<ul style="list-style-type: none"> <li>Supply cord and connector.</li> <li>Temperature sensor in the cooling compartment.</li> </ul>
E3	E3 on display Durafresh.	<ul style="list-style-type: none"> <li>The appliance continues to function, the basic function is guaranteed.</li> <li>A temperature failure in the Durafresh compartment.</li> <li>Repair is carried out by authorized Service.</li> </ul>	<ul style="list-style-type: none"> <li>Supply cord and connector.</li> <li>Temperature sensor in Durafresh compartment.</li> </ul>
LL	LL on display.	<ul style="list-style-type: none"> <li>Active function Child lock.</li> <li>When pressing any key, LL appears on the display.</li> <li>Cancel Child lock function by long pressing the key (bell).</li> </ul>	
Buzzer/Flash	<ul style="list-style-type: none"> <li>Flashing of the set temperature of the cooling and Durafresh</li> <li>Intermittent audible sound for 5 [min] at the beginning of each</li> </ul>	<ul style="list-style-type: none"> <li>High temperature alarm.</li> <li>Too frequent opening of the door, or door open too long.</li> <li>Door not closed correctly (possible impurities on door).</li> <li>There was no electricity for a longer period.</li> <li>There is too much foodstuffs in the appliance.</li> <li># Press the bell symbol and check the food.  Flashing remains</li> </ul>	<ul style="list-style-type: none"> <li>Supply cord and connector.</li> <li>Door switch.</li> <li>Temperature sensor.</li> <li>Thermal fuse (option).</li> <li>Defrosting heater (option).</li> <li>Connecting clamps.</li> <li>compressor.</li> <li>The operation of cooling system elements (leakage).</li> </ul>
Buzzer/Flash	<ul style="list-style-type: none"> <li>Flashing WiFi symbol or Alarm.</li> <li>Continuous tone buzzer.</li> </ul>	<ul style="list-style-type: none"> <li>Open door alarm.</li> <li>The alarm is canceled by closing the door or by pressing the</li> <li>The alarm is automatically canceled after 10 [min].</li> <li>In standby mode alarm does not work.</li> </ul>	<ul style="list-style-type: none"> <li>Supply cord and connector.</li> <li>Magnet on/in the door.</li> <li>Door switch.</li> </ul>
Buzzer/Flash	<ul style="list-style-type: none"> <li>Flashing the temperature of the cooling compartment +8, Dur</li> <li>Intermittent audible sound for 5 [min] at the beginning of each</li> </ul>	<ul style="list-style-type: none"> <li>Alarm by power failure.</li> <li># Press the bell symbol and check the food.  Flashing remains</li> </ul>	<ul style="list-style-type: none"> <li>Temperature sensor.</li> <li>The operation of cooling system elements (leakage).</li> </ul>
P2, 2P, P	P2, 2P on display.	<ul style="list-style-type: none"> <li>Appliance is in production mode.</li> <li># Switch the device off/on from the power supply twice.</li> </ul>	<ul style="list-style-type: none"> <li>Connecting cable and connector.</li> <li>Power board.</li> <li>Logic board.</li> <li>Temperature sensor.</li> <li>The operation of cooling system elements (leakage).</li> </ul>