

Error	Problem	Cause or remedy	Process (service technician)
F10	F10 on display.	• Water Inlet fault.   Too much water	• Drain pump. • Outlet hose. • Flowmeter. • Electro valve. • Wiring harness. • Aqua stop sensor.
F11	F11 on display.	• Water outlet fault.   Drain pump c	• Drain pump calibration. • Drain pump. • Wiring harness.
F12	F12 on display.	• Water Inlet fault.   Flowmeter did	• Flowmeter. • Electro valve. • Control unit.
F40	F40 on display.	• Leakage on the inlet valve.   Flow	• Electro valve. • Pressure sensor. • Hoses.
F41	F41 on display.	• Heating fault.   In case of heater f	• Heater. • Temperature sensor. • Pressure sensor. • Circulation pump. • Control unit.
F42	F42 on display.	• Temperature sensor fault (Detect	• Temperature sensor. • Wiring harness. • Control unit.
F43	F43 on display.	• Pressure sensor fault. • Repair is c	• Pressure sensor. • Control unit. • Wiring harness.
F44	F44 on display.	• Turbidity sensor fault. • Repair is c	• Turbidity sensor. • Wiring harness. • Control unit.
F45	F45 on display.	• Diverter valve fault. • Repair is car	• Diverter valve. • Wiring harness.
F52	F52 on display.	• Water level 1 fault. • Repair is carr	• Pressure sensor. • Electro valve. • Flowmeter. • Check air break. • Check drain hose.
F53	F53 on display.	• Water level 2 fault. # Clean the filt	• Drain pump. • Flowmeter. • Electro valve. • Clean filter. • Check drain hose.
F54	F54 on display.	• Float switch fault.   Float switch a	• Check appliance for leakage. • Floater microswitch. • Wiring harness. • Drain pump. • Control unit.
F56	F56 on display.	• Circulation pump fault. • Repair is	• Circulation pump. • Control unit. • Wiring harness.
F61	F61 on display.	• Water tank fault. • Repair is carri	• Water tank valve. • Pressure sensor. • Clogged water tank or hose.